125V DC STATION BATTERY "A" SIZING and VOLTAGE DROP
JAF-CALC -2609 Rev. 2

LOCA w/LOOP

| Source Panel | Load | LOCA w/ LOOP Start Time | LOCA w/ LOOP Stop Time | 13.3rd Voltage | 13.3rd Current | 13.4rd Voltage | 13.4rd Current | 14.4th Voltage | 14.4th Current | 14.5th Voltage | 14.5th Current | 15th Voltage | 15th Current | 15.7th Voltage | 15.7th Current | 17th Voltage | 17th Current | 17.5th Voltage | 17.5th Current | 17.8th Voltage | 17.8th Current | 18th Voltage | 18th Current | 18.2nd Voltage | 18.2nd Current | 18.3rd Voltage | 18.3rd Current | 18.4th Voltage | 18.4th Current | 19.4th Voltage | 19.4th Current | 19.5nd Voltage | 19.5nd Current | 23.2nd Voltage | 23.2nd Current | 23.3th Voltage | 23.3th Current | 42.9th Voltage | 42.9th Current | 43rd Voltage | 43rd Current | 44th Voltage | 44th Current | 44.01st Voltage | 44.01st Current | 55th Voltage | 55th Current | 1st min Voltage | 1st min Current | 1st min 0.1 sec Voltage | 1st min 0.1 sec Current | 1st min 3.5 sec Voltage | 1st min 3.5 sec Current | 2nd min Voltage | 2nd min Current | 2nd min 0.1 sec Voltage | 2nd min 0.1 sec Current | 2nd min 0.2 sec Voltage | 2nd min 0.2 sec Current | 2nd min 1.2 sec Voltage | 2nd min 1.2 sec Current | 2nd min 1.3 sec Voltage | 2nd min 1.3 sec Current |
|---|---|---