

FITZPATRICK LRA DRAWING LIST

Drawing	Sheet Number	Title	Filename
LRA-FB-8A-0	1	Flow Diagram Reactor Bldg Vent & Cooling System 66	lra-fb-08a_31
LRA-FB-10H-0	1	Flow Diagram Reactor Bldg Service Water Cooling System 66	lra-fb-10h_40
LRA-FB-16A-0	1	Flow Diagram Turbine Area Heating, Ventilation & Cooling System 67	lra-fb-16a_28
LRA-FB-16B-0		Flow Diagram Pipe and Cable Tunnel Heating, Ventilation and Cooling Systems 67 and 69	lra-fb-16b_16
LRA-FB-16C-0	1	Flow Diagram Emergency Generator Bldg Ventilation and Heating System 92	lra-fb-16c_09
LRA-FB-35E-0		Flow Diagram Control Room Area Service and Chilled Water System 70	lra-fb-35e_34
LRA-FB-45A-0		Flow Diagram Control and Relay Rooms Heating and Ventilation System 70	lra-fb-45a_41
LRA-FB-45C-0	1	Flow Diagram Adminstration & Control Room Heating Ventilation & Air Conditioning System 72	lra-fb-45c_20
LRA-FB-45E-0		Flow Diagram Screenhouse Ventilation and Cooling System 73	lra-fb-45e_02
LRA-FB-48A-0		Flow Diagram Fire Protection Water Piping System 76	lra-fb-48a_33
LRA-FB-49A-0	1	Flow Diagram Fire Protection Water Piping System 76	lra-fb-49a_40
LRA-FB-49B-0	1	Flow Diagram Fire Protection Water Piping System 76	lra-fb-49b_09
LRA-FB-56A-0		Flow Diagram CO2 and Foam Fire Extinguishing System	lra-fb-56a_12
LRA-FB-60A-0		Ventilation RCIC Area & Safety Related Pump Rooms	lra-fb-60a_04

LRA-FM-15B-0		Flow Diagram Reactor Bldg Cooling Water System 15	lra-fm-15b_26
LRA-FM-16A-0	1	Flow Diagram Off Gas System 01-107	lra-fm-16a_51
LRA-FM-17A-0	1	Flow Diagram Radwaste System 20	lra-fm-17a_35
LRA-FM-18A-0	1	Flow Diagram Drywell Inerting C.A.D. and Purge System 27	lra-fm-18a_55
LRA-FM-18B-0	1	Flow Diagram Drywell Inerting C.A.D. Purge and Containment Differential Pressurization System 27	lra-fm-18b_37
LRA-FM-18C-0		Flow Diagram NUREG 0578 Implementation and Post Accident Sampling System 27	lra-fm-18c_19
LRA-FM-18D-0		Flow Diagram Containment Hydrogen and Oxygen Sampling System 27	lra-fm-18d_14
LRA-FM-19A-0	1	Flow Diagram Fuel Pool Cooling and Cleanup System 19	lra-fm-19a_40
LRA-FM-20A-0	1	Flow Diagram Residual Heat Removal System 10	lra-fm-20a_70
LRA-FM-20B-0		Flow Diagram Residual Heat Removal System 10	lra-fm-20b_62
LRA-FM-21A-0		Flow Diagram Standby Liquid Control System 11	lra-fm-21a_36
LRA-FM-22A-0		Flow Diagram Reactor Core Isolation Cooling System 13	lra-fm-22a_52
LRA-FM-22B-0	1	Flow Diagram RCIC Turbine Lube Oil System 13	lra-fm-22b_18
LRA-FM-23A-0	1	Flow Diagram Core Spray System 14	lra-fm-23a_49
LRA-FM-24A-0		Flow Diagram Reactor Water Cleanup System 12	lra-fm-24a_63
LRA-FM-25A-0		Flow Diagram High Pressure Coolant Injection System 23	lra-fm-25a_68
LRA-FM-25B-0		Flow Diagram High Pressure Coolant Injection Lube Oil System 23	lra-fm-25b_31
LRA-FM-26A-0		Flow Diagram Reactor Water Recirculation System 02-2	lra-fm-26a_51
LRA-FM-27A-0	1	Flow Diagram Control Rod Drive System 03	lra-fm-27a_37
LRA-FM-27B-0	1	Flow Diagram Control Rod Drive System 03	lra-fm-27b_33
LRA-FM-29A-0	1	Flow Diagram Main Steam System 29	lra-fm-29a_53
LRA-FM-33D-0	1	Flow Diagram Condensate System 33	lra-fm-33d_26

Drawing	Sheet Number	Title	Filename
LRA-FM-34A-0	1	Flow Diagram Feedwater System 34	lra-fm-34a_59
LRA-FM-38A-0	1	Flow Diagram Vacuum Priming and Air Removal System 38	lra-fm-38a_38
LRA-FM-39A-0	1	Flow Diagram Breathing, Instrument and Service Air System 39	lra-fm-39a_50
LRA-FM-39B-0	1	Flow Diagram Service Air System 39	lra-fm-39b_32
LRA-FM-39C-0	1	Flow Diagram Instrument Air Reactor Bldg & Drywell System 39	lra-fm-39c_26
LRA-FM-44A-0	1	Flow Diagram Nuclear Equipment Drains System 44	lra-fm-44a_30
LRA-FM-46A-0	1	Flow Diagram Service Water System 46	lra-fm-46a_79
LRA-FM-46B-0	1	Flow Diagram Emergency Service Water System 46 & 15	lra-fm-46b_48
LRA-FM-46C-0	1	Flow Diagram Service Water System 46	lra-fm-46c_16
LRA-FM-47A-0		Flow Diagram Nuclear Boiler Vessel Instruments System 02-3	lra-fm-47a_46
LRA-FM-48A-0		Flow Diagram Standby Gas Treatment System 01-125	lra-fm-48a_29
LRA-FM-49A-0	1	Flow Diagram Drywell/Torus Leak-Rate-Analyzer System 16-1	lra-fm-49a_27
LRA-FM-93A-0		Flow Diagram Fuel Oil Lines Emergency Diesel Generators System 93	lra-fm-93a_22
LRA-FM-93C-0		Flow Diagram Engine Cooling & Lubrication Oil Emergency Diesel Generators System 93	lra-fm-93c_08
LRA-FM-94A-0	1	Flow Diagram Air Start-Up Lines Emergency Diesel Generators System 93	lra-fm-94a_13