

TABLE 3.6-1 (Continued)

VALVE NUMBER INSIDE/OUTSIDE			FUNCTION	TESTABLE DURING PLANT OPERATION	ISOLATION TIME (Sec) INSIDE/OUTSIDE	
C. <u>Containment Purge and Exhaust</u>						
1.	VS-D-5-3B	VS-D-5-3A	Containment Purge Exhaust	No	8 (1)	8 (1)
2.	VS-D-5-5B	VS-D-5-5A	Containment Purge Supply	No	11 (1)	8 (1)
3.		VS-D-5-6	Containment Purge Vacuum Breaker	No	N/A	N/A
D. <u>Manual</u>						
1.	ICH-181	MOV-CH308A	Seal Injection Water to RC Pump	No	N/A	N/A
2.	ICH-182	MOV-CH308B	Seal Injection Water to RC Pump	No	N/A	N/A
3.	ICH-183	MOV-CH308C	Seal Injection Water to RC Pump	No	N/A	N/A
*4.	MOV-CH142		Reactor Coolant System Letdown	Yes	N/A	N/A
*5.	MOV-CC112B3	1CCR-252	CCH from RHR Hx & RHR Pump Seal Coolers	Yes	N/A	N/A
*6.	MOV-CC112A3	1CCR-251	CCH from RHR Hx & RHR Pump Seal Coolers	Yes	N/A	N/A
*7.	MOV-CC112A2	1CCR-247	CW to RHR Hx & RHR Pump Seal Coolers	Yes	N/A	N/A
*8.	MOV-CC112B2	1CCR-248	CCW to RHR Hx & RHR Pump Seal Coolers	Yes	N/A	N/A
#9.		MOV-FW-151A	Auxiliary Feedwater	Yes	N/A	N/A
#10.		MOV-FW-151B	Auxiliary Feedwater	Yes	N/A	N/A
#11.		MOV-FW-151C	Auxiliary Feedwater	Yes	N/A	N/A
#12.		MOV-FW-151D	Auxiliary Feedwater	Yes	N/A	N/A
#13.		MOV-FW-151E	Auxiliary Feedwater	Yes	N/A	N/A
#14.		MOV-FW-151F	Auxiliary Feedwater	Yes	N/A	N/A
#15.		MOV-RW104A	Riverwater to Recirc. Spray Hx	Yes	N/A	N/A
#16.		MOV-RW104C	Riverwater to Recirc. Spray Hx	Yes	N/A	N/A
#17.		MOV-RW104B	Riverwater to Recirc. Spray Hx	Yes	N/A	N/A
#18.		MOV-RW104D	Riverwater to Recirc. Spray Hx	Yes	N/A	N/A

(1) Applicable in modes 5 & 6 only. The provisions of specification 3.0.4 are not applicable.