
REACTOR COOLANT PUMP 2-1 (SEE NOTE 3)
REACTOR COOLANT PUMP 2-2 (SEE NOTE 3)
REACTOR COOLANT PUMP 1-1 (SEE NOTE 3)
REACTOR COOLANT PUMP 1-2 (SEE NOTE 3)
REACTOR VESSEL & CONTAINMENT
CONTAINMENT
SEE NOTE 3
SEE NOTE 3
SEE NOTE 3