FUEL POOL HEAT EXCHANGER
2E27*
FUEL POOL ION EXCHANGER
*2T5
2F32
FUEL POOL ION EXCHANGER STRAINER
2F4A
2F4B
FUEL POOL FILTERS
FUEL POOL PUMPS
2P40A*
2P40B*
*2P56
FUEL POOL PURIFICATION PUMP
2F2
2FIT4
AIR TRAP
2M72
1/2" SIPHON BREAKER
2M73 2M74
1/2" SIPHON BREAKER
2M75
1/2" SIPHON BREAKER
2F-367
FUEL TILT PIT
2M-18
FUEL POOL SKIMMER CONNECTION
2H6
FAILED FUEL ASSEMBLY CONTAINER
2P86
CASK LOADING PIT
FUEL TILT PIT PUMP
CASK LOADING AREA
FLEXIBLE HOSE
REFUELING CANAL
FUEL POOL
REFUELING WATER TANK M-2286 (H-1)
BORATED WATER M-2231,H,I,S (G-1)
FROM SERVICE WATER HEADER #2 M-2201,H,I (H-5)
SERVICE WATER HEADER II M-2218 SH 1 (H-5)
SERVICE WATER M-2201,A,I,S (C-8)
SERVICE WATER M-2201,A,I,S (C-9)
DRAIN COLLECTION HEADER M-2231,SH 1,K (G-7)
RESIN SLUICE M-2231,SH 1 (H-3)
RESIN ADDITION M-2231,SH 1 (G-1)
SPENT RESIN TANK M-2224 (G-1)
FLUSH LINE M-2231,SH 1 (H-3)
PCH M-2231,SH 1,K (G-7)
PCH M-2231,SH 1,G (B-7)
PCH M-2231,SH 1,G (B-8)
PCH M-2231,SH 1,B (H-8)
PCH M-2231,SH 1,S (H-7)
PCH M-2231,SH 1,S (H-1)
GCH M-2231,S (B-4)
GCH M-2231,S (B-4)
HOLDUP TANKS M-2231,SH 1 (E-8)
CONTAINMENT SUMP M-2231,SH 1 (C-1)
SPRAY HEADER DRAIN HEADER M-2229,SH 1 (G-8)
TELL-TALE DRAIN
INTERNALS REMOVED
LOCAL SAMPLE
GASKET AIR TEST CONN.
FUEL TRANSFER TUBE (IT)
SIAS #1
SIAS #2
SAC
NOTE 9
NOTE 6
NOTE 8
SEE NOTE 7
NOTE 10
AT MOD.
CE, BECHTEL
SWAGELOK CRAWFORD FITTING, PNAS M-2122 SECT. CC (TYP. FOR 5)
EL 405'-0" N.L.L.
EL 401'-6" N.L.L.
EL 405'-0"
EL 401'-6"
EL 385'-0"
EL 405'-0"
EL 401'-6"
EL 385'-0"
EL 405'-0"
EL 401'-6"
EL 385'-0"