

Fire Protection Significance Determination Process (SDP) P-108

September 2009

United States
Nuclear Regulatory Commission



DISCLAIMER NOTICE

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, or any of their employees, makes any warranty, expressed or implied, or assumes any legal liability of responsibility for any third party's use, or the results of such use, or any information, apparatus, product or process disclosed in this report, or represents that its use by such third party would not infringe privately owned rights.

Fire Protection Significance Determination Process (SDP) P-108

Course Presented by

Dana Kelly, INL

Dana.Kelly@inl.gov
208-360-0538

Mike Calley, INL

Michael.Calley@inl.gov
208-526-9230



*September 29 – October 1, 2009
NRC Professional Development Center
Bethesda, MD*

Acknowledgments:

The INL gratefully acknowledges Mr. Steven Nowlen, Sandia National Laboratories. Mr. Nowlen originally developed the Fire Protection SDP – Application Training for New Analysis Procedure (P-108) Course. Mr. Nowlen facilitated this course by providing his original P-108 course material.

Outline

- **Day 1:**
 - **Module 1: Introduction to Fire SDP philosophy and example problem**
 - **Module 2: Concepts and terminology**
 - **Module 3: Overview of the new process**
 - **A quick trip through Phases 1 and 2**
- **Day 2:**
 - **Module 4: Details of Phase 1**
 - **Module 5: Details of Phase 2**
- **Day 3:**
 - **Module 5: Details of Phase 2 (continued)**
 - **Module 6: Special Topics**
 - **Discussion and Closing**

Module 1: Introduction to Fire SDP Philosophy and Example Problem

- **Objective: Describe the philosophy underlying the Fire Protection Significance Determination Process (SDP)**
 - **This section provides a very brief and high level overview of the process, including similarities and differences with the SDP for internal events**

Fire SDP Overview

- **Entry conditions (what is a finding?)**
- **Risk significance (color assignment) criteria**
- **Duration factor plays the same role as in internal events SDP**
- **Focus on credible fire scenarios**
 - **You are asked to develop one or more credible fire scenarios**
- **Use of plant notebooks and pre-solved worksheets for post-fire safe shutdown**
- **Your use of judgment is critical!**

Fire SDP Overview

- Process is tied rather directly to fire PRA
 - Simplified versions of common PRA methods
 - “The equation” is the PRA equation – that just means we multiply factors directly instead of adding their exponents
 - Scenarios are tied to a timeline
 - Timing of critical events drives Phase 2 in particular
 - Time to damage versus time to suppression
- Many steps, but each step is focused
 - Each step is aimed at a specific bit of information needed to quantify fire risk increase

Fire SDP Overview

- **Aggressive efforts to identify Green findings as soon as information is sufficient to justify**
 - **Low degradation findings are automatically Green**
 - **“Screen-to-Green” checks included in most steps**
- **Much supporting guidance**
 - **That’s why the “book” is so thick!**
 - **Most inputs come from look-up tables**
 - **Use made of Fire Dynamics Tools (FDTs)**
 - **Excel spreadsheets**

Fire Dynamics Tools

- **The NRR Fire Dynamics Tools (FDT) are used to support analysis:**
 - **Temperature conditions in the fire plume and hot gas layer**
 - **Fire detection/suppression actuation times**
 - **Cable fire spread**
 - **Pool fires and radiant heating**
 - **Documented in NUREG-1805**
 - **V&V documented in NUREG-1824**

Desired Outcomes of Fire SDP

- **Quickly identify Green findings**
- **If a finding is potentially greater than Green, the Phase 2 analysis should be:**
 - **Systematic**
 - **Repeatable**
 - **Accurate**
 - **Defensible**
- **Reduce analysis burden at all levels (Phase 1, 2, 3)**

Problems With Fire SDP Have Not Yet All Been Solved

- **Some issues remain pending in context of SDP treatment – the guidance for assessment is just not there**
- **If you hit one of these, and can't call it Green, you are probably heading towards Phase 3**

Issues That Remain Pending

- **“Cross-cutting issues”**
 - We assume finding is tied to one (or more) fire areas
 - Some findings cut across many fire areas
 - The process works for these, but you need to select a representative set of fire areas to analyze risk change
 - Area selection guidance has not been developed
 - Examples:
 - Broad performance issues for manual fire fighting
 - Some circuit analysis issues
 - Some manual actions issues

Issues That Remain Pending

- **Guidance for treatment of Main Control Room (MCR) fires and MCR abandonment is incomplete**
 - **No explicit guidance in Phase 2 on how to assess conditional probability of MCR abandonment**
 - **There are worksheets for alternate and remote shutdown**
 - **MCR fire frequency is nominally covered, but guidance on partitioning is a bit weak**
 - **Likelihood of a fire in a specific panel or cabinet**
 - **MCR manual suppression is covered by a suppression curve, but key is failure of prompt suppression, and that guidance is still lacking**

Issues That Remain Pending

- **Complex manual actions**
 - **Worksheets are provided to assess manual actions but, due to simplified approach, won't give much credit to complex action sets**
 - **Complex actions sets may require additional analysis (e.g., Phase 3)**

Issues That Remain Pending

- **There are processes underway to address most of these issues – SDP will incorporate guidance as it develops:**
 - **Manual fire-fighting**
 - **Circuit analysis**
 - **Manual actions**

A Word About Complexity

- **The process looks complex, but hope to convince you it is really pretty straight-forward**
- **The systematic structure and supporting guidance should aid efficiency and effectiveness**
- **You may not be fully convinced this week, but hope you will come to see this as you become more experienced with the process**
 - **Practice and regular use will be a key**
 - **If you only do Fire SDP once a year, you may struggle**

Example Problem

- Go over background material for example problem

Module 2: Concepts, Terminology, and Fire Scenario Introduction

Concepts, Terminology, and Fire Scenario Introduction

- **Objectives:**
 - **Outline the basic quantification process used in fire PRA**
 - **Define the factors that go into quantification**
 - **Define key terms**
 - **Point out some “red flag” issues along the way**
 - **Define fire scenarios and introduction of details**

Why?

- **Why spend time here? Why not jump right into the SDP process?**
 - **The fire SDP structure is the same as that used in a general fire PRA**
 - **If you understand this basis, life will be much easier**
 - **Lots of unique terminology**
 - **Meanings need to be clear**
 - **Allows us to look at the technical quantification process separate from the SDP regulatory decision-making process**

Risk

- Risk combines the likelihood that something undesirable will happen with the severity of resulting consequences
 - From PRA Basics: $\text{Risk} = \text{Frequency} \times \text{Consequences}$
- In context of NRC mission, risk is most correctly measured based on potential public health consequence:
 - Atomic energy act empowers NRC to establish and enforce standards governing the commercial use of nuclear materials and facilities as "the Commission may deem necessary or desirable in order to protect health and safety and minimize danger to life or property."
- That implies risk measures such as acute and latent fatalities
 - Probabilistic Safety Goals of 1986 established goals for acute and latent fatalities
- Primary measure of fire risk is Core Damage Frequency (CDF)
 - CDF is a surrogate for public health consequence risk
 - Large Early Release Frequency (LERF) not used for fire protection SDP

How We Estimate Fire CDF

- **We calculate fire CDF using four basic factors:**
 - **Fire Frequency (F)**
 - **Severity Factor (SF)**
 - **Probability of Non-Suppression (PNS)**
 - **Conditional Core Damage Probability (CCDP)**
- **Note that SF is often folded into fire PRA as a part of 'F' or 'PNS' depending on analyst preference – we'll call it out explicitly in Fire SDP**

How We Estimate Fire CDF

- For one fire scenario:
 - $CDF_i = F_i * SF_i * PNS_i * CCDF_i$
- We do as many fire scenarios as we need to, add them up (carefully), and that is our fire CDF estimate
- We can roll up CDF values at different levels:
 - One fire scenario
 - One fire ignition source – multiple scenarios
 - One fire area – multiple ignition sources
 - One building – multiple fire areas
 - Entire unit
 - Entire plant site

How We Estimate Fire CDF

- Fire SDP focuses on fire area roll-up
 - Question: what is the risk increase caused by a specific performance deficiency?
 - Deficiency is assumed to be tied to one or two fire areas
 - We estimate risk for the impacted area(s)
- Remember that some issues cut across fire areas – examples:
 - Post-fire manual actions
 - Manual fire brigade
 - Circuit analysis issues
- We don't do cross-cutting issues (yet)
 - You have to tie your finding to one or more fire areas
 - No guidance for picking areas for cross-cutting issue

Fire Frequency (F):

- **Definition: The rate at which fire occurs during some time period**
 - Time period is generally 12 months of at-power reactor operations
 - One reactor-year (ry)
- **Estimated based on past experience**
 - A bunch of statistics that we won't go into
 - Database used contains nearly 1,500 reported “fires”
 - EPRI Fire Event Database updated through 2002
 - Industry average capacity factors are used
- **General units of measure:**
 - fires / ry

Pop Quiz – Who Is This?



Fire Frequency: F

- You often hear that not all events reported as a fire hold the potential to challenge nuclear safety – TRUE!
 - We took care of this for you
 - Events were “screened out” if there was no potential for a safety challenge
 - Ignition frequencies provided for SDP should not be adjusted beyond the instructions provided – leave that to Phase 3
 - In the end, we retained about 1/2 of the fire “events” as potentially challenging
 - Actual percentage retained depends on nature of fire source

Fire Frequency and Event Screening

- **Sounds easy, but you can really cause problems if you're not careful**
- **Important to maintain independence**
 - **Other steps in analysis take credit for things you might be “counting” when you screen the events**
 - **Basic assumptions tend to flow from the “event set” you choose as representing your fire frequency**
- **Be skeptical when someone argues that particular events are not relevant to fire risk**
 - **They may be right, but their basis for rejecting an event cannot align with another factor credited elsewhere**

Fire Frequency: F

- **Statistics give us the frequency of a fire somewhere, or involving something, in the plant**
 - Tied to either location or fire ignition source
 - We assume this frequency is the same for all plants
- **What we want is the frequency of a fire involving a specific ignition source in a specific location**
 - For most cases, component based fire frequencies do this directly
 - e.g., you get frequency for one motor
 - In some cases we apply a partitioning factor to reflect a critical location out of all possible locations
 - Area ratio factors – e.g., transients, welding
 - Linear feet ratio factors – e.g., cable trays, control room panels

If We Need A Room Fire Frequency

- **We can use a generic area fire frequency based on average industry experience for similar fire areas**
 - **SDP through step 2.3**

OR

- **We can add up the contributions from all the individual sources in that particular fire area**
 - **SDP beginning with Step 2.4**
- **Don't expect to get the same answer either way**
 - **For SDP, the generic values are intended to be slightly conservative – especially in Phase 1**
 - **This won't be a universal truth, but differences should not be significant**

Grouping Fire Ignition Sources

- You can group some individual ignition sources, and treat the group rather than each individual
 - Common example is electrical cabinets/panels
 - Want all members of the group to be “the same”
 - Fire characteristics
 - Proximity to targets (damage) and secondary combustibles (fire spread)
- Frequency for group is sum of frequency of each individual source
 - For group of 10 panels, fire frequency = 10 times frequency for a single panel
- More on grouping later

Severity Factor (SF)

- **General fire PRA definition: value between 0 and 1 reflecting fraction of all fires that are considered threatening in the context of a specific fire scenario**

Severity Factor: Fire SDP

- **SDP approach ties SF to fire intensity**
 - **Current PRA practice, but not same as typical IPEEE for fires**
- **Why tie SF to fire intensity?**
 - **Burn an electrical panel 10 times, and you'll probably get 11 different burn profiles**
 - **This reflects fact that fire intensity profile is inherently uncertain**
 - **All things being equal, some fires will remain small, some will get big**
 - **If it takes a big fire to cause problems (and it usually does) we reflect this through the severity factor**

Severity Factor

- **SDP Definition: SF = the fraction of fires big enough to cause damage to at least one potential target and/or spread fire to secondary combustibles**
 - We calculate “big enough” on a case-specific basis
 - How big is the fire [use peak heat release rate (HRR)]
 - How close are the damage targets and secondary combustibles
 - We use two HRR values for each fire ignition source
 - Lower HRR represents 90% of all fires: $SF = 0.9$
 - Larger HRR represents worst 10% of fires: $SF = 0.1$
 - In effect we split each fire ignition source into two possible fires – one big and one not so big
 - If only the larger HRR leads to spread/damage, we end up with a net severity factor of 0.1

Illustration of SF Concept:

- Even looking at a single fire ignition source, not all fires will be the same, some will be big, some not so big
- Fire intensity or heat release rate (HRR) is not a point value!
- We model uncertainty in peak HRR with a probability distribution




Illustration of SF Concept - General

- We look for the smallest fire leading to fire damage and/or spread
- Fires that large or larger are the “risky” ones
- We tie SF to the fraction of fires that large or larger





Illustration of SF Concept - SDP

- For SDP we use a simplified version
- Two fire HRR values for each fire ignition source
 - Expected value represents 90% of fires
 - High confidence value represents 10% of fire

Peak HRR Probability Distribution



SDP Approach – Quick Review

- **SDP uses simplified version of general approach**
 - **Two fire intensity (HRR) values used represent the full distribution for each fire ignition source**
 - **‘Expected’ and ‘High Confidence’ or 75% and 98%**
 - **Words/numbers not important – it’s the concept that counts**
 - **Assigned SF of 0.9 and 0.1 respectively**
 - **Assess the spread/damage potential for these two HRR values**
 - **The final results combine these two cases using SF as, in effect, a weighting factor on fire frequency**
 - **Net severity factor depends on whether each intensity value causes damage**

Obtaining HRR Values

- **Discrete HRR values were suggested based on Fire Risk Requantification Study (FRRS)**
- **Review and discussion by SDP fire scenario team including NRC and Industry reps. – an expert panel**
- **Final values ultimately accepted for SDP**
- **Some adjustments made in FRRS approach to reflect SDP team/panel input**

Severity Factor – Past Red Flag Issue for Fire PRA

- One of the most widely and easily abused aspects of fire PRA
 - Steve Nowlen’s professional view
 - Some cases of abusive application were seen in the IPEEEs, so take care when someone cites those to you
- You’ll see severity factors crediting:
 - Prompt suppression, self-extinguished fires, fires that caused no trip, fires that did not spread, fires that did not damage secondary components, fires in non-vital areas, and ... the kitchen sink

Severity Factor (Summary)

- Before you buy, remember the three “D”’s of PRA:
 - Dependency, dependency, dependency
 - The same factors may be accounted for elsewhere in the PRA – either implicitly or explicitly
 - When you see the use of one (or heaven forbid more than one) severity factor in quantification you have to ask if they are double counting somewhere

Probability of Non-Suppression (PNS)

- **Definition: PNS** - The conditional probability that, given the fire, the fire will not be suppressed prior to the failure of a specific set of damage targets or ignition of secondary combustibles
 - **Key 1:** Specific to a particular fire ignition source scenario
 - May be a grouped set of fire ignition sources
 - **Key 2:** Specific to a particular target set
 - **PNS** is the conditional probability that, given the fire, these targets will fail or ignite

Target Set

- **A collection of components and/or cables that may be threatened by a postulated fire**
 - **Target set could be anything from one cable to everything in the fire area**

Target Set

- The target set either survives or fails as a whole
 - If you need to break down a target set, you really need to define more than one target set
- Target sets can be progressive if needed – one set represents expansion of another smaller set:
 - Target Set 1 = {item 1}
 - Target Set 2 = {items 1,2,3} ...
 - Helpful if two trains are threatened but separated (for example)
- Different fire ignition sources may have the same target set or different target sets

Target Set

- **For any one fire ignition source:**
 - **Most often one target set is enough**
 - **You may define a series of expanding target sets, if necessary, to reflect growth and spread of the fire**
 - **Don't go overboard – one, two, or at most three, should handle most situations**

Target Set

We'll come back to this a bit later, but...

- **Poor cable routing data actually makes this step easier**
 - **If you don't know where specific cables are, you basically have to assume the worst**
- **Good cable routing data can actually complicate the choice**
 - **You may be tempted to define many target sets as each tray becomes involved**
 - **Don't: keep it simple**

Back to PNS...

- **PNS is a ‘probabilistic’ horse race: time to damage versus time to suppression**
- **Time to damage depends on:**
 - **How close targets are to the fire**
 - **Target failure threshold**
 - **How big the fire is**
 - **Possibly: How quickly fire spreads**
- **The plant’s chances of putting the fire out within this time depend on:**
 - **What sort of fixed fire suppression capability is available**
 - **Timing of manual fire response (e.g., the brigade)**

Time to Damage

- We can predict time to damage in three steps:
 - Set the damage threshold
 - Targets are usually cables
 - Two basic cable types: thermoset (robust) and thermoplastic (wimpy)
 - Predict the exposure conditions
 - Plume, direct radiant heating, or hot gas layer
 - Estimate temperature or heat flux at target location using Fire Dynamics Tools (FDTs)
 - Convert exposure condition to damage time
 - SDP uses look-up tables

Cable Insulation/Jacket Types

- **Thermoplastic**
 - Melt if heated, solidify if cooled,
 - Drip and burn as a liquid pool
 - More wimpy
 - Examples:
 - Polyethylene (PE)
 - Polyvinylchloride (PVC)
- **Thermoset**
 - Don't melt
 - Burn/char in place if heated enough
 - More macho
 - Examples:
 - Cross-linked polyethylene (XLPE or XPE)
 - Ethylene-Propylene rubber (EPR)

Damage Thresholds

- **Screening Criteria for Assessment of Ignition and Damage Potential of Electrical Cables**

Cable Type:

<u>Thermoplastic</u>	<u>(Metric)</u>	<u>(English)</u>
Heat Flux:	6 kW/m ²	0.5 BTU/ft ² s
Temperature:	205°C	400°F

<u>Thermoset</u>	<u>(Metric)</u>	<u>(English)</u>
Heat Flux:	11 kW/m ²	1.0 BTU/ft ² s
Temperature:	330°C	625°F

Damage Time Look-Up Table (Example*)

*Table A7.1 from IMC 0609, Appendix F, Attachment 7, 02/28/05

Table A7.1 - Failure Time-Temperature Relationship for Thermoset Cables		
Exposure Temperature		Time to Failure (minutes)
°C	°F	
$330 \leq T < 335$	$625 \leq T < 634$	28
$335 \leq T < 340$	$634 \leq T < 642$	24
$340 \leq T < 345$	$642 \leq T < 651$	20
$345 \leq T < 350$	$651 \leq T < 660$	16
$350 \leq T < 360$	$660 \leq T < 680$	13
$360 \leq T < 370$	$680 \leq T < 700$	10
$370 \leq T < 380$	$700 \leq T < 716$	9
$380 \leq T < 390$	$716 \leq T < 735$	8
$390 \leq T < 400$	$735 \leq T < 752$	7
$400 \leq T < 410$	$752 \leq T < 770$	6
$410 \leq T < 430$	$770 \leq T < 805$	5
$430 \leq T < 450$	$805 \leq T < 840$	4
$450 \leq T < 470$	$840 \leq T < 880$	3
$470 \leq T < 490$	$880 \leq T < 915$	2
$T \geq 490$	$T \geq 915$	1

Damage Time Look-Up Table (Example*)

*Table A7.2 from IMC 0609, Appendix F, Attachment 7, 02/28/05

Table A7.2 - Failure Time-Temperature Relationship for Thermoplastic Cables		
Exposure Temperature		Time to Failure (minutes)
°C	°F	
$205 \leq T < 220$	$400 \leq T < 425$	30
$220 \leq T < 230$	$425 \leq T < 450$	25
$240 \leq T < 245$	$450 \leq T < 475$	20
$245 \leq T < 260$	$475 \leq T < 500$	15
$260 \leq T < 275$	$500 \leq T < 525$	10
$275 \leq T < 290$	$525 \leq T < 550$	8
$290 \leq T < 300$	$550 \leq T < 575$	7
$300 \leq T < 315$	$575 \leq T < 600$	6
$315 \leq T < 330$	$600 \leq T < 625$	5
$330 \leq T < 345$	$625 \leq T < 650$	4
$345 \leq T < 355$	$650 \leq T < 675$	3
$355 \leq T < 370$	$675 \leq T < 700$	2

Automatic Suppression Time

- **We can predict the time to actuation for an automatic suppression system using a simple spreadsheet tool**
 - **e.g., a sprinkler head looks just like a heat detector**
 - **Fire Dynamics Tools (FDTs) from NRR**
- **This gives us a number**
 - **x:x minutes:seconds**

PNS for Automatic Suppression

- We don't want to do a straight yes/no comparison between damage time and suppression time – this can be very misleading
 - Damage time = 10 min
 - Suppression time = 9 min, 30 sec.
 - Nominally suppression wins, but what is your confidence in this answer?
 - Is it really yes/no or fail/no fail?
 - To acknowledge uncertainties in the time estimates, we use the margin between damage time and suppression time

Probability Table for Automatic Suppression


Probability of Non-suppression for Fixed Fire Suppression Systems Based on the Absolute Difference Between Damage Time and Suppression Time

Time Delta: ($t_{\text{Damage}} - t_{\text{Suppress}}$)	PNS_{Fixed}
Negative Time up to 1 Minute	1.0
> 1 Minute to 2 Minutes	.95
> 2 Minutes to 4 Minutes	.80
> 4 Minutes to 6 Minutes	.5
> 6 Minutes to 8 Minutes	.25
> 8 Minutes to 10 Minutes	.1
> 10 Minutes	0.0

PNS and Manual Suppression

- **PNS for manual suppression estimated from empirical fire duration curves**
 - The vast majority of fires are manually suppressed
 - We get fire duration data for enough of the reported fires to develop a fire duration curve
- **Pick the appropriate fire duration curve**
- **Estimate ($t_{\text{damage}} - t_{\text{detection}}$)**
 - Remember that detection triggers manual response, but damage time (t_{damage}) is measured from time of ignition ($t = 0$)
- **Pick off $\text{PNS}_{\text{manual}}$**
 - Values also available in look-up table

Duration Curve Example:



Auto vs. Manual Suppression

- If auto is present, we assume it will be primary suppression means
- If auto fails, manual suppression is always the backup
 - We assume that a water-based automatic suppression system will fail on demand 2% of the time
 - Gaseous systems – 5%
- If no auto system, then manual suppression is all there is

Manual Fixed Suppression

- **Fixed fire suppression systems that have no automatic actuation mechanism – human action is required**
- **No hard/fast rule possible – use following:**
 - **Estimate detection time**
 - **Estimate physical response time**
 - **Review decision criteria and estimate decision-making time**
 - **Nominal value is 2 minutes**
 - **Increase if circumstances warrant**
 - **Actuation time is sum of these three**

Combining Manual and Auto-Suppression

- If auto-suppression is present, it is assumed first line of defense
- Auto systems don't always work:
 - Water based system ~2% failure on demand
 - Gaseous systems ~5% failure on demand
 - Values reflect both reliability and availability (out-of-service time)
- Manual is always available as a backup

Combining Manual and Auto-Suppression

For Water-based systems:

$$\text{PNS}_{\text{scenario}} = (0.98 \times \text{PNS}_{\text{fixed-scenario}}) \\ + (0.02 \times \text{PNS}_{\text{manual-scenario}})$$

For Dry-pipe and Gaseous systems:

$$\text{PNS}_{\text{scenario}} = (0.95 \times \text{PNS}_{\text{fixed-scenario}}) \\ + (0.05 \times \text{PNS}_{\text{manual-scenario}})$$

$$** \text{PNS}_{\text{scenario}} \leq \text{PNS}_{\text{manual-scenario}}$$

Special Consideration For Degraded Gaseous System

- If gaseous suppression system cannot maintain adequate suppressant concentration for sufficient time to assure fire extinguishment, then manual fire-fighting must do the final mop-up
 - The degraded gaseous system cannot permanently extinguish the fire, but does buy the fire brigade some additional response time
 - We assume that the fire will be held in check during the time that the fire suppressant concentration is maintained at design level
 - Upon dissipation of suppressant fire will re-flash – we assume it will pick up right where it left off

Degraded Gaseous Systems

- **To get PNS we need to compare damage time to a suppression time-line with the following elements:**
 - **Actuation time for gaseous system (manual or automatic as normally analyzed)**
 - **The probability table that reflects our confidence that system actuation is timely compared to fire damage time**
 - **Hold time / soak time for design concentration that system can deliver**
 - **Manual response following loss of concentration**
 - **Details in Module 5**

Conditional Core Damage Probability (CCDP)

- **Definition:** The conditional probability that, *given fire-induced loss of a target set*, safe shutdown efforts will fail to achieve a safe and stable state, thus resulting in core damage
 - Safe and stable generally means hot shutdown
 - Risk analyses don't generally look at ability to achieve cold shutdown

CCDP

- **CCDP is calculated using a post-fire safe shutdown plant response model**
 - **Screening estimates may only credit the designated post-fire safe shutdown path**
 - **For more detail, we use a broader plant response model that may credit components and systems beyond Appendix R**
 - **SDP uses the plant notebooks and pre-solved worksheets**

CCDP

- **We won't go into depth on this topic, but some high level rules:**
 - **To credit a system or function, you must have reasonable assurance that it will not be damaged by the fire - your judgment counts**
 - **We do credit manual actions – guidance is provided – but complex sets of actions will likely get little credit in Phase 2**
 - **Spurious operations may be a part of CCDP calculation – you may need help here**

That's pretty much it.

$$\mathbf{CDF_i = F_i * SF_i * PNS_i * CCDP_i}$$

Of course, the devil's in the details...

More On Fire Scenarios

- **Definition:** A fire scenario is a postulated sequence of events starting with the ignition of a fire and ending either in plant safe shutdown or core damage.

Fire Scenario

- **What is a Fire Scenario:**

**(Fire Scenario) = (fire ignition source scenario)
and (fire growth and damage scenario)
and (fire suppression scenario)
and (plant SSD response scenario)**

Change any element and you have a new fire scenario!

Fire Ignition Source Scenario

- **Definition:** Defines the physical characteristics of the fire that will develop for a particular fire ignition source – key factors:
 - Placement of fire “origin” – how close is origin to targets
 - Heat release rate (HRR)
- **SDP bins fire sources by type, and ties characteristics to each type**
 - Five HRR values used to characterize all (simple) fires

Table 2.3.1 - Mapping of General Fire Scenario Characterization Type Bins to Fire Intensity Characteristics

Fire Size Bins	Generic Fire Type Bins with Simple Predefined Fire Characteristics					
	Small Electrical Fire	Large Electrical Fire	Indoor Oil-Filled Transformers	Very Large Fire Sources	Engines and Heaters	Solid and Transient Combustibles
70 kW	75 th Percentile Fire				75 th Percentile Fire	75 th Percentile Fire
200 kW	98 th Percentile Fire	75 th Percentile Fire			98 th Percentile Fire	98 th Percentile Fire
650 kW		98 th Percentile Fire	75 th Percentile Fire	75 th Percentile Fire		
2 MW			98 th Percentile Fire			
10 MW				98 th Percentile Fire		

Fire Origin

- The fire origin is a conceptual point at which we will assume the fire originates.
 - Horizontal placement determines what is overhead and therefore within the fire plume
 - Vertical placement will affect plume temperature for exposure of overhead targets
- Choice depends on the nature of the fire source
 - We'll come back to this later

Heat Release Rate (HRR)

- **HRR characterizes the fire intensity or the amount of heat generated by a fire per unit time**
 - **Typical units are either KW or BTU/hr**
- **This is generally the most critical of all fire characterization input values**
- **Remember – SDP ties fire intensity to severity factor**

Convective / Radiative Fractions

- Heat transfer from fire is via two primary mechanisms:
 - Convective transfer – The mixing of hot fire products with ambient air resulting in direct heating of the surrounding air that in turn causes buoyancy and fire plume behaviors
 - Radiative transfer – the luminosity of a fire's flame zone results in direct radiant heating of opaque targets (including soot-laden air)
- Recommended split fractions are:
 - 0.7 convective, 0.3 radiative
 - Paired values should add to 1.0

Fire Growth and Damage Scenario

- **Definition: characteristics of fire spread to secondary combustibles if such occurs, and the behaviors leading to failure of an identified thermal damage target set**
 - You must define a target set – we already covered this
 - Damaging conditions may be created either due to burning of the ignition source alone, or due to fire spread
 - If fire ignition source alone is not enough, and fire cannot spread, then damage is not possible

SDP Fire Damage States (FDS)

- **FDS0 – loss of only the fire ignition source**
 - Not analyzed as a contributor to increase in CDF (screen to Green)
- **FDS1 – localized damage near (especially directly above) the fire ignition source**
 - Key factors: plume heating, upward spread of fire, and direct radiant heating
- **FDS2 – widespread damage within a single fire area**
 - Key factors: horizontal fire spread, hot gas layer, and failure of degraded raceway fire barriers
- **FDS3 – fire damage impacting two (or more) fire areas (room-to-room)**
 - Key factor: failure of an inter-compartment fire barrier element

Fire Detection and Suppression

- **We credit all available means of fire detection and suppression**
- **Detection is important mainly because it triggers the manual response**
 - **Plant personnel become aware of the fire**
 - **Fire procedures may kick in (check plant process for when this really happens)**
 - **The fire brigade is activated**
- **Fixed automatic suppression systems require no prior detection signal, but usually are tied to alarm circuits**

Fire Suppression

- Remember, in SDP it's a horse race
 - Question is not so much “does suppression fail?”
 - But rather, “does suppression fail to put out the fire before damage occurs?”
- All fires are put out (or go out) eventually – we want to know if suppression is timely in the context of our specific target set

CCDP

- **CCDP characterized plant/operator response to the fire**
- **Objective is safe shutdown (hot shutdown)**
- **This part can be complex – you will likely want to get your SRA involved to support this effort**

Developing a Fire Time Line

- Key events on the time line
 - Fire ignites (define this as time = 0)
 - Fire is detected ($t_{\text{detection}}$)
 - Manual/operator response begins
 - Fire brigade is activated
 - Target set fails (t_{damage})
 - Remember: t_{damage} measured from $t = 0$
 - Automatic suppression activates ($t_{\text{supp_auto}}$)
 - Manual suppression is successful ($t_{\text{supp_man}}$)
- Order of these events is TBD!



Idaho National Laboratory

Intentionally Left Blank

Module 3: Process Overview

Process Overview

- A quick once-through – flow chart style
- Objective: familiarize you with the process
 - Its structure
 - Steps and tasks
 - How the pieces fit together

Ground Rules For This Section

- **Process questions are OK**
- **Please hold questions on Step/Task details**
 - **We'll come back and cover the details of both Phase 1 and Phase 2**
 - **There will be plenty of time for questions on the details**


Process Overview – Scope

- We are talking about Phase 1 and 2 only
- Phase 3 is still out there
 - Anything goes for Phase 3 – that's not our job!

Phase 1 – Objective and Basis


- **Phase 1 objective:** identify findings that can be categorized as **Green** without detailed analysis
- **Phase 1 basis:** combines concepts of “qualitative screening” and very preliminary “quantitative screening” from fire PRA

Figure F.1 - Phase 1 Flow Chart



Phase 2 – Objective and Basis

- **Objective:** Estimate the CDF increase associated with a finding
- **Basis:** Simplified versions of current fire PRA methods – we borrow:
 - Structure
 - Assumptions
 - Numerical values
 - Analysis Tools
 - Quantification approach





Idaho National Laboratory

Module 4: Phase 1 Details

Phase 1 Details

- **We will cover each step and task in Phase 1:**
 - **Purpose/objective**
 - **What, why, how**
 - **Input/output**
 - **Supporting guidance**

Phase 1- Step 1.1

- **Assign a finding category**
 - **A convenient way to bin (classify) findings**
- **Later decisions will depend on the assigned category:**
 - **Degradation ratings**
 - **Quantitative screening criteria**
 - **Types of fire scenarios that are relevant**
- **Look for underlying issue leading to a finding and assign category accordingly**

The Finding Categories Are...

(as shown in 0609, App F, Table 1.1.1)

- **Cold Shutdown**
- **Fire Prevention and Administrative Controls**
- **Fixed Fire Protection Systems**
- **Fire Confinement**
- **Localized Cable or Component Protection**
- **Post-Fire Safe Shutdown**

Cold Shutdown Findings

- Findings related to the ability to achieve and maintain cold shutdown
- Examples:
 - An issue related to RHR so long as:
 - RHR is not needed/relied upon to support post-fire hot shutdown
 - Spurious operation of RHR component(s) cannot compromise the hot shutdown capability

Fire Prevention and Administrative Controls

- Findings relating to combustible control programs, training, permit processes, activity specific fire watches, etc.
- Examples:
 - Violation of combustible control limits
 - Failure to follow hot work permitting requirements
 - Failure to properly execute hot work fire watches
 - Deficiencies in fire-protection related training
 - Records keeping issues

Fixed Fire Protection Systems

- Findings related to:
 - Fixed fire detection
 - Fixed fire suppression (automatic or manual)
 - Fire watches posted as a compensatory measure for a fixed fire protection system outage or degradation
- Examples: Sprinklers, deluge, room flooding gas systems, smoke or heat detectors, etc.
- Excludes fire separation features
 - Passive features such as fire barriers, doors, dampers, seals, wraps
 - Water curtains (as a fire barrier element)

Fire Confinement

- Findings related to fire barriers and barrier elements that separate fire areas
 - Walls/floors/ceilings
 - Penetration seals
 - Water curtains when used as a separation element
 - Fire and/or smoke dampers
 - Fire doors
- Definition of fire area: portion of building or plant that is separated from other areas by rated fire barriers adequate for the fire hazard (R.G. 1.189).

Localized Cable or Component Protection

- **Passive fire protection features meant to protect cables and/or components from fire damage given fires within the same fire area**
 - **Cable and raceway fire wraps**
 - **Radiant heat shields**
 - **Spatial separation**
 - **Fire barriers between fire zones within a fire area**

Post-Fire Safe Shutdown (SSD)

- Findings that directly impact systems or functions identified in the post-fire SSD analysis or systems or functions relied upon for post-fire SSD
 - Completeness of the
 - Post-fire SSD component list
 - Post-fire SSD analysis
 - Post-fire plant response procedures
 - Alternate shutdown (e.g., manual actions)
 - Remote shutdown and control room abandonment
 - Circuit-analysis-related issues (e.g., spurious operation)

Fire Barriers vs. Safe Shutdown

- **Example: A hole in a raceway fire barrier (made during maintenance) was not properly sealed upon completion of maintenance activities. The barrier protects a cable associated with the designated post-fire SSD path.**
 - **This one may be obvious - a localized cable or component protection issue**

Fire Barriers vs. Safe Shutdown

- **Example 2: The licensee committed to providing fire wraps for certain post-fire SSD cables. In one case, the wrong cable tray was wrapped, and the correct tray was left unprotected**
 - **This is a Localized Fire Barrier issue**
 - **The underlying issue is failure to provide the barrier that was committed to**
 - **Treat as highly degraded raceway fire barrier**

Fire Barriers vs. Safe Shutdown

- **Example 3: A cable associated with the designated post-fire SSD path is found to be exposed (with no fire wrap) in a fire area where it is required to support safe shutdown. Further review reveals that the licensee failed to identify the cable as a required component.**
 - **This is a Safe Shutdown Finding – failure to identify a required component is the underlying issue.**

Fire Barriers vs. Safe Shutdown

- **Example 4: It is determined that spurious operation of a particular circuit could compromise the designated post-fire SSD path (open a diversion path) for the area being inspected. A cable that could cause spurious operation is found to be exposed (with no fire wrap) in the fire area being inspected. The licensee did not identify the circuit as an associated circuit; hence, the cable is not on the post-fire SSD component list.**
 - **This is a Safe Shutdown Finding – failure to identify an associated circuit is the underlying issue.**

Relationship of Finding Categories to SDP Process

- Category assigned 'maps' to elements of the analysis process:
 - Fire prevention and administrative controls
 - Increases fire frequency
 - Fixed Fire Protection
 - Increases time to suppression
 - Fire Confinement
 - Focus placed on FDS3 Scenarios
 - Localized Cable or Component Protection
 - Focus placed on scenarios that damage protected component
 - Post-Fire Safe Shutdown
 - Increases CCDP

Finding Categories – A Final Note

- Once assigned, category does not change

Phase 1 – Step 1.2

- **Assign a degradation rating**
 - In general pick one: **High – Moderate – Low**
 - **Exceptions:**
 - **No Moderate rating for Fire Prevention and Administrative Controls (call it either High or Low)**
 - **For Fire Confinement and Localized Cable and Component Protection (fire barriers) Moderate rating is split into “Moderate A” and “Moderate B”**
- **Degradation rating criteria depend on finding category (from Step 1.1)**
 - **See Attachment 2 for Degradation Rating Guidance**

Questions On Degradation Rating Guidance?

- **Don't intend to cover Attachment 2 guidance in detail, but open to questions and/or discussion**
- **Time for reading IMC 0609 will be provided in afternoon sessions**

Degradation Rating – Final Note:

- Once set, degradation rating doesn't change

Phase 1 – Step 1.3

- **Initial Qualitative Screening**
 - Based on a series of yes/no questions
 - Questions are phrased so that a “yes” will mean screen to Green
 - Wording is a tad awkward in some cases
- **Two Tasks:**
 - Task 1.3.1 applies to all findings
 - Task 1.3.2 applies only to Fire Confinement findings

Phase 1, Task 1.3.1 – Qualitative Screening

- Screening based on only two questions
 - Any finding Screens to Green if:
 - Degradation rating is Low
 - OR
 - Finding only affects the ability to reach and maintain **COLD SHUTDOWN** conditions*
 - Example: RHR system issue so long as RHR is not required for post-fire hot shutdown
 - *Note: If the post-fire SSD path involves a direct transition to cold shutdown, and the finding impacts the ability of the plant to successfully complete this transition, then the finding would not screen to Green based on this question, and the analysis should continue.

A Note On Low And Green

- A finding does not have to have a Low degradation rating in order to be Green
 - If degradation rating is Low, finding is Green, but...
 - Even if degradation rating is greater than Low, finding may still be Green
- Even a High degradation rating may turn out to be Green
 - Moderate and High degradation findings will generally pass forward to Phase 2
 - Some exceptions for Moderate Fire Confinement findings
 - Phase 2 may still conclude that finding is Green
 - We don't re-assign the degradation rating to Low just because Phase 2 screens the finding to Green

Phase 1, Task 1.3.2

- **Applies to Fire Confinement findings with Moderate degradation only**
 - **Recall: Fire Confinement findings tied to fire area (App. R) boundaries**
- **Screening based on seven questions**
- **Screen to Green if inter-area fire scenarios will not be risk significant even given the degradation**
 - **No unique targets in adjacent room**
 - **Low likelihood of fire barrier failure:**
 - **Adequate performance time even given degradation**
 - **Defense In Depth (DID) – fire suppression capability**
 - **DID – additional passive fire protection**
 - **No substantive fire hazards present**
 - **Cannot challenge barrier**

Fire Confinement – A Note On Terminology

- PRA practice is a bit loose here with respect to terminology
- You may see reference to:
 - Inter-area fires, inter-compartment fires, room-to-room fires, multi-room fires
- They all mean basically the same thing
 - Watch “fire area” versus “fire compartment” definitions
 - With respect to SDP usage of “fire area”, we mean the Appendix R context (RG 1.189):
 - The term "fire area" as used in Appendix R means an area sufficiently bounded to withstand the hazards associated with the area and, as necessary, to protect important equipment within the area from a fire outside the area..
- For SDP, Fire Confinement relates only to the fire barriers that separate one fire area from another

Exposing vs. Exposed Compartment

- **Remember: Fire Confinement findings always involve two fire areas**
 - **“Exposing compartment” is fire area where you will assume that fire starts**
 - **“Exposed compartment” is the fire area on the other side of the degraded fire barrier**
- **Remember to look both ways...**
 - **You will pick one orientation for actual analysis**
 - **Generally pick orientation where fire in exposing compartment will create greatest challenge to the degraded fire barrier**

Exposing vs. Exposed Compartment

- **Indicators for choosing exposing compartment:**
 - **More challenging fire ignition sources**
 - **Higher intensity (e.g., a source of big oil fires is an obvious choice)**
 - **Fire ignition sources adjacent to degraded barrier**
 - **Lacks automatic fire suppression coverage**
- **Point is that you need to develop a fire scenario leading to spread through a degraded barrier, so you need a significant fire source in the exposing compartment, with no potential for rapid suppression**

Task 1.3.2, Question 1

- Q: Will the barrier in its degraded condition provide a 2-hour or greater fire endurance rating?**
- If Yes – Screen to Green, no further analysis required**
 - If No – Continue to next question**
 - Degraded fire endurance rating is based on degradation rating and nominal rating**
 - Moderate A means 66% of nominal rating**
 - Moderate B means 33% of nominal rating**
 - High degradation means no credit or zero endurance rating**
 - This one won't help very often**
 - Mod. A on a 3 hour barrier gives equivalent of 2 hours**
 - A non-rated barrier that you judge to be equivalent to 2 hours**

Task 1.3.2, Question 2

Q: Is there a non-degraded automatic gaseous room-flooding fire suppression system in the exposing fire area?

- If Yes – Screen to Green, no further analysis required**
- If No – Continue to next question**
- We are crediting Defense-In-Depth measures**
- Gaseous systems must be non-degraded – no performance issues**
- We are looking at a feature that will disrupt the initial fire growth**

Task 1.3.2, Question 3

Q: Is there a non-degraded or no more than moderately degraded automatic full-area water-based fire suppression system in the exposing area?

- If Yes – Screen to Green, no further analysis required**
 - If No – Continue to next question**
- Again, a DID credit**
- For water-based system, we do allow credit in the case of Moderate degradation**
 - System works, but has some performance issues**
- Again, looking for something that disrupts initial fire growth**

Task 1.3.2, Question 4

Q: Can it be determined that the exposed fire area contains no potential damage targets that are unique from those in the exposing fire area (damage targets may include post-fire SSD components or other plant components whose loss might lead to a demand for safe shutdown (e.g., a plant trip))?

- If Yes – Screen to Green, no further analysis required**
- If No – Continue to next question**
- Wording is awkward – ‘yes = Green’**
- Point is you need unique targets in exposed area to make an inter-area fire scenario significant**
 - If all possible targets are also in the exposing fire area, spread across boundary adds nothing new: no increase in fire CDF**

Task 1.3.2, Question 5

- **Q: Are all potential damage targets in the exposed fire area (as described in question 4) provided with passive fire barrier protection with no more than a moderate degradation that will provide a minimum of 20 minutes fire endurance?**
 - **If Yes – Screen to Green, no further analysis required**
 - **If No – Continue to next question**
- **Credit for passive fire barrier elements as a DID element so long as barrier is good for at least 20 minutes**
 - **Fire would need to breach two passive barriers with no more than moderate degradation – both barriers will get some credit**
 - **Scenario starts to look pretty unlikely**

Task 1.3.2, Question 6

- **Q: Is a non-degraded or no more than moderately degraded partial-coverage automatic water-based fire suppression system installed in the exposing fire area and are all the fixed fire ignition sources included within the zone of coverage for this system?**
 - **If Yes – Screen to Green, no further analysis required**
 - **If No – Continue to next question**
- **A lot like Question 3, but we relax full coverage requirement**
 - **As long as all fixed fire sources are covered by the suppression system, we give DID credit**

Task 1.3.2, Question 7

- **Q: Does the degraded barrier provide a minimum of 20 minutes fire endurance protection and are the fixed fire ignition sources and combustible or flammable materials positioned such that, even considering fire spread to secondary combustibles, the degraded barrier or barrier element will not be subject to direct flame impingement?**
 - If Yes – Screen to Green, no further analysis required
 - If No – Continue to Step 1.4
- **We relax the performance requirement on the degraded barrier if we won't have direct flame impingement on the barrier**

Phase 1 – Step 1.4

- Initial Quantitative Screening
- Two quantitative factors considered:
 - Duration factor (DF)
 - Fire frequency for the fire area (F_{area})
- If product of these two is “low enough,” screen to Green
- In practice, this is unlikely to happen
 - Fire area fire frequencies are pretty conservative
 - Screening criteria are still pretty stringent
 - We’ll need DF and F_{area} for Phase 2, so do this step anyway, just don’t expect to screen
 - Step had more meaning in previous versions of the SDP, may come back into play in the future

Task 1.4.1 – Duration Factor

<u>Duration of the Degradation</u>	<u>Duration Factor (DF)</u>
< 3 days	0.01
3 - 30 days	0.1
> 30 days	1.0

Task 1.4.2 – Fire Frequency for the Fire Area

- F_{area} from look-up table – IMC 0609, App F, Table 1.4.2
- Intended to be somewhat conservative, but this won't be universally true
 - If fire area contains more than the average number of fire ignition sources, the component-based fire frequency for the full fire area as calculated in Phase 2 may be higher!
- Differences should be minor
 - You need to cross an order of magnitude boundary for difference to be significant
 - You may use the Phase 2 approach if table value does not fit your case - use your judgment

Special Cases: Hot Work and Transient Combustible Findings

- If finding is against hot work program, only hot work fires are relevant
- If finding is against transient combustible controls, only transient fires are relevant
- We give you an upper bound estimate of fire area hot work and transient fire frequency values to use in this step rather than the full room fire frequency

Table 1.4.2 - Generic Fire Area Fire Frequencies

Room Identifier/Limited Specific Findings	Generic Fire Frequency
Auxiliary Building (PWR)	4E-2
Battery Room	4E-3
Cable Spreading Room - Cables Only	2E-3
Cable Spreading Room - Cables Plus Other Electrical Equipment	6E-3
Cable Vault or Tunnel Area - Cables Only	2E-3
Cable Vault or Tunnel Area - Cables Plus Other Electrical Equipment	6E-3
Containment - PWR or non-inerted BWR	1E-2
EDG Building	3E-2
Intake Structure	2E-2
Main Control Room	8E-3
Radwaste Area	1E-2
Reactor Building (BWR)	9E-2
Switchgear Room	2E-2
Transformer Yard	2E-2
Turbine Building - Main Deck (per unit)	8E-2
Hot Work Issues Only	2E-3
Combustible Controls Program Issues Only	5E-3

Task 1.4.3 – Screening Check

- **Task 1.4.3 sets Phase 1 quantitative screening criteria**
- **Screening criteria imply an implicit level of risk credit for non-impacted DID elements**
 - **Criteria depend on the finding category assigned in Step 1.1**
 - **Remember, if you ever get below 1E-6, finding is Green so no screening criterion is ever more stringent than 1E-6**

Task 1.4.3 – Screening Check

$$\Delta(\text{CDF})_{1.4} \approx \text{DF} * F_{\text{area}}$$

Table A1.2 - Phase 2 Screening Step 1 Quantitative Screening Criteria

Assigned Finding Category (from Step 1.1):	$\Delta \text{CDF}_{2,1}$ Screening Value	
	Moderate Degradation	High Degradation
Fire Prevention and Administrative Controls	N/A	1E-6
Fixed Fire Protection Systems	1E-5	
Fire Confinement	1E-5	
Localized Cable or Component Protection	1E-5	
Post-fire SSD	1E-6	

Example Problem – Phase 1

- **Fill out Attachment 1 to IMC 0609, App. F for the example problem**



Idaho National Laboratory

Intentionally Left Blank

Module 5: Phase 2 Details

Module 5: Phase 2 Details

- **We will cover each step and task in Phase 2:**
 - **Purpose/objective**
 - **What, why, how**
 - **Input/output**
 - **Supporting guidance**
 - **Some examples – focus on a step/task**

Step 2.1: Independent SSD Path First Screening Assessment

- This step involves a coarse assessment of the designated post-fire SSD path
 - Can we credit SSD path prior to development of detailed scenarios
 - If so, what is appropriate screening CCDP value
- If we can show that the path is independent of any fire scenarios we might develop, we will credit that path right away for all scenarios
 - Often, we may “attack” the redundant SSD path in one or more scenarios, so we won’t give credit yet
- SSD credit/analysis gets refined after development of scenarios in Step 2.4 and again in Step 2.8
 - This is just a first rough cut

Task 2.1.1: Identify the Designated Post-Fire SSD Path

- The SSD Path must meet all of the following criteria:
 - Must be identified as the designated post-fire SSD path in the plant's fire protection program
 - Must be supported by a documented post-fire SSD analysis consistent with regulatory requirements
 - Must be documented and included in the plant operating procedures
- BTW: If the answer to any one of these is “No,” then you may well have an SSD finding to deal with

Task 2.1.2 – SSD Nominal Unavailability

- **SSD path is assigned a nominal unavailability factor**
 - **Possible values are limited to:**
 - **1.0, 0.1, or 0.01**
- **1.0 means no credit – appropriate if there are questions as to adequacy of SSD**
 - **For example, given an SSD finding**
- **Note: “unavailability” = CCDP in the equation**

Unavailability Factors

Table 2.1.1 - Total Unavailability Values for SSD Path Based Screening CCDP

Type of Remaining Mitigation Capability	Screening Unavailability Factor
1 Automatic Steam-Driven (ASD) Train: A collection of associated equipment that includes a single turbine-driven component to provide 100% of a specified safety function. The probability of such a train being unavailable due to failure, test, or maintenance is assumed to be approximately 0.1 when credited as "Remaining Mitigation Capability."	0.1
1 Train: A collection of associated equipment (e.g., pumps, valves, breakers, etc.) that together can provide 100% of a specified safety function. The probability of this equipment being unavailable due to failure, test, or maintenance is approximately 1E-2 when credited as "Remaining Mitigation Capability."	0.01
Operator Action Credit: Major actions performed by operators during accident scenarios (e.g., primary heat removal using bleed and feed, etc.). These actions are credited using three categories of human error probabilities (HEPs). These categories are Operator Action = 1.0 which represents no credit given, Operator Action = 0.1 which represents a failure probability between 5E-2 and 0.5, Operator Action = 0.01 which represents a failure probability between 5E-3 and 5E-2. Credit is based upon the following criteria being satisfied: (1) sufficient time is available; (2) environmental conditions allow access, where needed; (3) procedures describing the appropriate operator actions exist; (4) training is conducted on the existing procedures under similar conditions; and (5) any equipment needed to perform these actions is available and ready for use.	1.0, 0.1 or 0.01

Task 2.1.3 – SSD Path Independence

- Independence has special context here:
 - SSD path should not be challenged in any of the fire scenarios we might later develop
 - SSD path components/cables are not included in the target set for any of our possible fire scenarios
 - Fire scenario definition comes later, so this requires a bit of foresight
- If path might be compromised in any potential fire scenario, we don't credit the path yet
 - We still want unavailability, because later we may credit the SSD path in those scenarios where the path does survive
- SSD Path Independence Check Criteria listed in IMC 0609, App F, Table 2.1.2

Independence Criteria:

- These should be assured by virtue of Appendix R compliance:
 - The licensee has identified and analyzed the SSD SSCs required to support successful operation of the SSD path.
 - The licensee has identified and analyzed SSCs that may cause mal-operation of the SSD path (e.g., the required and associated circuits).
 - The licensee has evaluated any manual actions required to support successful operation of the SSD path and has determined that the actions are feasible.

Independence Criterion – Manual Actions

- This criterion might be an issue for plants taking credit for long term actions after the fire is out:
 - All manual actions take place outside the fire area under analysis
- Implication of this criterion:
 - No operator actions that take place within the fire-affected area will be credited in Phase 2
 - Feasibility of actions will be reconsidered during Phase 3 so make a note of these in your documentation

Independence Criteria – Circuit Analysis

- These three relate to circuit analysis:
 - The licensee has conducted an acceptable circuit analysis
 - Should be a given
 - Any known unresolved circuit analysis issues that could adversely impact the operability of the designated SSD path are identified.
 - No known circuit analysis issues (e.g., a known spurious operation issue) for exposed cables should hold the potential to compromise operability of the identified SSD path.

Independence Criteria – Exposed Cables

- “Exposed cables” guidance:
 - Cables within the fire area under analysis are not considered exposed if
 - they are protected by a non-degraded raceway fire barrier with a minimum 3-hour fire endurance rating.
- OR
- they are protected by a raceway fire barrier with a minimum one-hour fire endurance rating, and the area is provided with automatic detection and suppression capability, and none of these elements is found to be degraded.

Independence Criteria – Exposed Cables

- “Exposed cables” guidance (cont.)
 - Cables in an adjoining fire area are not considered exposed if the fire barrier separating adjoining fire area from the fire area under analysis is not degraded.
 - If the finding category assigned in Step 1.1 was “Fire Confinement,” cables located in the adjacent fire area are considered exposed unless they are protected by a non-degraded localized fire barrier with a minimum 1-hour fire endurance rating.

Independence Criteria

- Features discussed in previous two slides relate directly to Appendix R, III.G.2 separation strategies
- Basically, when we decide if cables are exposed or not exposed for purposes of SDP fire scenarios:
 - We do credit 3-hour separation as long as barrier is not degraded
 - We do credit 1-hour separation with auto detection and suppression as long as these features/systems are not degraded
 - We do not credit spatial separation within the same fire area
 - We do not credit exemptions or remote shutdown at this stage of analysis

Task 2.1.4 – Screening Check

- $\Delta CDF_{2.1} = DF \times (F_{Area}) \times CCDF_{2.1}$

Table A1.2 - Phase 2 Screening Step 1 Quantitative Screening Criteria		
Assigned Finding Category (from Step 1.1):	$\Delta CDF_{2.1}$ Screening Value	
	Moderate Degradation	High Degradation
Fire Prevention and Administrative Controls	N/A	1E-6
Fixed Fire Protection Systems	1E-5	
Fire Confinement	1E-5	
Localized Cable or Component Protection	1E-5	
Post-fire SSD	1E-6	

- $\Delta CDF_{2.1}$ is lower than the corresponding value in Table A1.2 - the finding screens to Green and the analysis is complete.
- $\Delta CDF_{2.1}$ is greater than or equal to the corresponding value in Table A1.2. The analysis continues to Step 2.2

Example Problem – Step 2.1

- Do Step 2.1 for the example problem

Step 2.2 – Fire Damage State (FDS) Determination

- The nature of the finding determines which types of fire scenarios **MAY** be relevant to risk increase
 - If nothing about a scenario changes as a result of the degradation, then the scenario is not relevant
- This step is a quick decision process to decide which FDSs need to be considered as you develop fire scenarios
- The most complex part of this step is Task 2.2.2, FDS3 screening

Task 2.2.1: Initial FDS Assignment

- Simple look up table:

Table 2.2.1 - FDS/Finding Category Matrix			
Finding Type or Category:	FDS1	FDS2	FDS3
Fire Prevention and Administrative Controls	Retain	Retain	Retain
Fixed Fire Protection Systems	Retain	Retain	Retain
Fire Confinement	N/A	N/A	Retain
Localized Cable or Component Protection			
Given a High degradation	Retain ⁽¹⁾	Retain	Retain
Given a Moderate degradation	N/A	Retain	Retain
Post-fire SSD	Retain	Retain	Retain

Note 1: For a highly degraded local barrier, the protected components/cables are treated as fully exposed and may be assumed damaged in FDS1 scenarios, depending on their proximity to the fire ignition source.

Task 2.2.2 – FDS3 Screening

- **We would really like to drop FDS3 if we can – most of the time you will**
 - **Multi-area scenarios are rarely risk significant as long as the barriers are intact**
- **If the inter-area barrier is degraded, you're stuck with FDS3**
 - **This screening task only applies to findings that are not in the Fire Confinement category**
 - **We already did an equivalent screening for Fire Confinement findings in Phase 1 (Step 1.3.2) so we do not repeat**

FDS3 Screening: Exposing and Exposed Areas

- Given that the finding category is anything other than Fire Confinement, the fire area you are inspecting is always the exposing fire area
 - The fire always starts somewhere in the exposing fire area
- The exposed fire area may be any adjacent fire area – up, down, sideways
 - You will be evaluating the potential risk due to fire spread to an exposed fire area
- You are going to look for a fire in the exposing fire area that is substantial enough to challenge the fire area boundaries and spread to the exposed fire area, causing additional unique damage there

FDS3 Screening: How It Works

- **Series of yes/no questions**
 - **Start in the exposing fire area – where the finding is**
 - **Apply the questions to each adjacent fire area as a potential exposed fire area**
 - **Look for any one exposing/exposed area pair that might give you a credible scenario**
 - **If FDS3 scenarios do not screen out, you will ultimately identify one area to act as the representative exposed fire area**
 - **Pick the worst case and go with it – usually based on interesting targets (e.g., redundant SSD path)**
 - **You won't analyze all combinations in detail**
- **Questions are virtually identical to those in Task 1.3.2**
 - **Same general intent and basis**
 - **Only difference is we assume the barrier between the fire areas is not degraded**
 - **Words relating to fire endurance rating of the barrier “in its degraded condition” are dropped**

Drop FDS3 If:

- Fire area boundaries for the exposing fire area have minimum 2-hour endurance rating
 - May have a mixed bag of barriers – some 2-hour, some not
 - Drop any room combinations that are separated by a 2-hour barrier
 - For the rest of the questions, focus only on those combinations that don't have 2-hour separation
- The exposing fire area has:
 - Non-degraded gaseous suppression, OR
 - No more than moderately degraded full-coverage water suppression, OR
 - Partial coverage water system that covers all fixed fire ignition sources
 - Meeting any one of these conditions is enough

Drop FDS3 If:

- For these three conditions, remember to focus on specific combinations of fire areas that lack 2-hour separation:
 - There are no unique targets in any exposed compartment, OR
 - Targets in any exposed compartment are at least 20 feet from the separating fire barrier and/or have passive protection with a one-hour fire endurance rating, OR
 - The fire barrier between fire areas has at least 20 minutes fire endurance, **AND** *fixed* ignition sources won't subject barrier to direct flame impingement
 - Fire ignition sources are well away from the barrier
 - (Meeting any one of these conditions is enough)

To Retain FDS3 You Must Have Found All of the Following:

- A somewhat weak barrier to at least one adjacent fire area (less than 2 hours endurance rating)
- Questionable or non-existent fixed suppression capability in exposing compartment
- Unique and exposed targets in the adjoining exposed fire area
- The potential for fire that can directly challenge that fire barrier element

It's not hard to develop an inter-area fire scenario out of that situation!

Step 2.2 – Summary

- At the end of this step you will be left with one, two, or three FDSs to consider in the development of fire scenarios
 - We still need to develop credible fire scenarios, but this step says we will at least look for scenarios corresponding to each retained FDS
- If you drop one or more FDSs, they never come back

Step 2.2 – One Last Point

- Step 2.2 only tells you that you need to consider the possibility of one or more fire scenarios for each FDS retained
- It does NOT say you MUST develop at least one fire scenario for each FDS
 - Some FDS states may simply not be credible
 - FDS2 in a fire area with inadequate combustibles to create a hot gas layer
- It also does not say every fire ignition source will lead to at least one scenario for each FDS retained
 - Some fire ignition sources might contribute to only one FDS and not to other FDSs even though the other FDSs were retained

Illustrative Example

Finding: A cable tray associated with the designated Train B SSD path should have been wrapped but was not (licensee wrapped the wrong tray)

- Finding Category: Localized Cable and Component Protection**
- Degradation: High**
- Task 2.2.1 says nominally retain FDS1, FDS2, FDS3**
- To complete example, let's assume:**
 - We know exactly where the train B tray is**
 - The train B tray is routed in the first (lowest) tray among a stack of trays directly above a bank of electrical panels**
 - There are various other panels and equipment in the fire area, and many train A cable trays**
 - FDS3 screened out in 2.2.2**

Illustrative Example

So let's develop scenarios!

- **General Observations: Fire Sources**
 - We have several fire sources around the room
 - The row of electrical panels directly below the train B tray is of particular interest, but other more remote sources may also be important

Illustrative Example – Sources Near Train B

Scenario development:

- Second key factor in scenario development is target sets:
- Targets of interest are:
 - Train A cables throughout the room
 - Specifics lacking so we must assume they are everywhere
 - Loss of any exposed tray causes loss of Train A
 - The cables in the unwrapped Train B tray
 - Can cause loss of post-fire SSD capability
- Implies we might have two target sets:
 - Target set 1: Loss of Train A cables only
 - Target set 2: Loss of both Train A and Train B cables
- Why not target set 3: Train B only?

Illustrative Example – Sources Near Train B

- For the bank of electrical panels directly below the unwrapped Train B tray:
 - First exposed cable tray has Train B
 - Loss of any tray assumed to cause loss of Train A
 - FDS1 scenarios get us loss of both Train A and B – Target set 2
 - Do we need FDS2?? Answer: NO
 - FDS2 scenarios can't add anything new
 - We already lost both trains, including the SSD train
 - For these sources, FDS1 scenarios are enough to characterize the risk change – Target set 2 applies

Illustrative Example – Remote Sources

- **What about fire sources remote from unwrapped tray?**
 - **FDS1 scenarios for remote sources will not damage train B cables – Target set 1 applies - Train A only**
 - **Question to ask yourself: Does the lack of a wrap on the train B cable tray change these remote-source FDS1 scenarios in any way?**
 - **Answer in this case: NO – FDS1 is not attacking the train B tray, so lack of thermal protection is irrelevant.**
 - **Result: Fires from remote sources leading to loss of train A only are not relevant to the finding against the train B wrap - FDS1 scenarios need not be pursued for these remote fire ignition sources**

Illustrative Example – Remote Sources

- **FDS2 scenarios – fire spreads to overhead cables causing a damaging hot gas layer**
 - **These scenarios can damage both the Train A and Train B cables**
- **Are these scenarios relevant?? ASOLUTELY!**
- **For the remote fire ignition sources the FDS2 scenarios characterize risk increase relevant to the finding**
 - **We don't need to analyze the FDS1 scenarios in detail for the remote fire ignition sources**

Illustrative Example

- To summarize:
 - Risk increase will be characterized by a combination of FDS1 and FDS2 scenarios
 - For the panels directly under the train B tray, we analyze FDS1 scenarios only
 - For the other remote fire ignition sources, we analyze FDS2 scenarios only
 - For this case, we probably can characterize risk with just two fire scenarios by appropriately grouping the fire ignition sources!

Summary of Illustrative Example

- Electrical panels directly below unwrapped Train B cables:
 - FDS1
 - ~~– FDS2~~
 - Sources remote from unwrapped Train B cables:
 - ~~– FDS1~~
 - FDS2
- Target Set 1: Train A cables only
 - Target Set 2: Train A and Train B cables
 - ~~• Target Set 3: Train B cables only~~

Example Problem – Step 2.2

- Do Step 2.2 for the example problem

Step 2.3 – Scenarios and Ignition Sources


- **Purpose of this step is to begin defining fire scenarios**
 - **That last illustrative example started us on this path!**
- **First point of focus is to identify fire ignition sources to be retained for further analysis**
 - **Identify and count fire ignition sources**
 - **Screen out non-threatening fire ignition sources**
 - **Revise room fire frequency based on retained fire ignition sources**
 - **Screening check using new room fire frequency**

Task 2.3.1 – Count Sources

- **For most cases, we use a component-based fire frequency, so first task is to count fire ignition sources**
 - **If you use spreadsheet, entering counting results automatically updates the fire frequency**
- **For transients, cables, and hot work fires, the area is ranked as High – Medium – Low**
 - **There is ranking guidance provided**
 - **Intent is to do a relative ranking – how does this fire area compare to other fire areas in the plant?**
- **Any questions on counting/ranking guidance??**

There Will Be Counting Challenges

- How many “distinct vertical sections” do you see?



Counting

- **Use your judgment!**
- **Goal is to get a reasonable estimate of the fire frequency**
 - **Avoid optimism but also avoid gross conservatism**
- **For the illustrated relay racks, two possible options are:**
 - **There are some distinct visible divisions between sections that could be counted as panel dividers**
 - **Q: How would this weigh against general plant practice and other electrical panels? Does it seem reasonable?**
 - **You could assume a “typical” vertical section is about 3 feet wide, and assign the relay racks a frequency based on the total linear feet of racks**

Task 2.3.1 – Special Cases

- **For some findings, only a specific subset of potential fire ignition sources is considered**
 - **High-degradation finding against combustible material controls – only transient fire ignition sources are relevant**
 - **High-degradation finding against hot work fire watch – only hot work fires are relevant**

Focus On What Changes

- **You want to focus on fire ignition sources where the finding causes a scenario to change, for example:**
 - **If a portion of a fire sprinkler system is out of service, focus on sources that would normally be covered but now are not**
 - **Given a lack of detection within a beam pocket, focus on fire ignition sources that are also within/under that same beam pocket**
- **Use your judgment and limit your search as appropriate**
 - **No different than what you are already doing**

Focus On What Might Prove To Be Credible

- **Don't waste time worrying about fire ignition sources that will clearly not yield a credible fire scenario:**
 - **If you have an issue in one corner of a reactor building, and there is a small fire source isolated at the opposite end of the building, Don't waste time worrying about that source**
 - **If it's obvious that the fire cannot spread enough to create a damaging hot gas layer, then you have no FDS2 and the scenario is not going to be credible**
- **Document your logic and move on.**

Task 2.3.2: Characterize Sources

- **We talk about simple and non-simple fire ignition sources**
 - **Simple: panels, other electrical fires, transformers, engines, heaters, transients**
 - **Non-simple: self-ignited cable fires, energetic arcing faults, transients that exceed nominal size, hot work fires, flammable liquids, hydrogen**
- **We are going to talk about simple sources now, we will cover non-simple sources in Module 6 (with examples)**

Task 2.3.2 – Simple sources

- **For simple sources, pull HRR values from the lookup table for each fire ignition source**
- **Two values for each source:**
 - **Lower value represents 90% of fires – the “expected value” or 75th percentile**
 - **Higher value represents upper 10% of fires – the “high confidence value” or 98th percentile**

Fire Characteristics Table

Table 2.3.1 - Mapping of General Fire Scenario Characterization Type Bins to Fire Intensity Characteristics

Fire Size Bins	Generic Fire Type Bins with Simple Predefined Fire Characteristics					
	Small Electrical Fire	Large Electrical Fire	Indoor Oil-Filled Transformers	Very Large Fire Sources	Engines and Heaters	Solid and Transient Combustibles
70 kW	75 th Percentile Fire				75 th Percentile Fire	75 th Percentile Fire
200 kW	98 th Percentile Fire	75 th Percentile Fire			98 th Percentile Fire	98 th Percentile Fire
650 kW		98 th Percentile Fire	75 th Percentile Fire	75 th Percentile Fire		
2 MW			98 th Percentile Fire			
10 MW				98 th Percentile Fire		

Task 2.3.2 – Simple Sources

- **Assign a location for the fire origin**
 - **For general fire ignition sources, place origin on top of the fire source**
 - **Motor, transformer, etc.**
 - **Exceptions:**
 - **Electrical cabinets/panels: 1 foot below the top of the panel**
 - **Transients: 2 feet above the floor at desired location**

Tasks 2.3.3 and 2.3.4 – Screening Ignition Sources

- **We need to screen ignition sources:**
 - **If we can damage or ignite any target, we keep the ignition source**
 - **If we cannot damage/ignite nearest target, we drop that ignition source**
- **Three considerations for damage/ignition:**
 - **Plume exposure**
 - **Radiant heating**
 - **Hot gas layer**
- **Screening is done in two tasks...**

Task 2.3.3 – Nearest Target

- In this task you identify the nearest and/or most vulnerable target to each fire source
 - Don't need to define a full target set (yet), just find the one most likely to fail/ignite
- Target can be either a damage or ignition target – it's all the same for this step
 - Target's function does not matter – does not need to be an SSD component, for example
- For now, we just want to know if the fire ignition source is capable of either damaging one or more potential targets OR spreading fire to secondary combustibles

Task 2.3.3 – Nearest Target

- **Look for targets directly above fire**
 - **Plume heating**
- **Look for targets off to the side**
 - **Radiant heating**
- **If nothing else, you will have some target for hot gas layer exposure**
- **If you can't find a target, you should not be in that room**

Task 2.3.3 – Nearest Target

- **Note target location relative to fire ignition source**
 - **Height above source**
 - **Horizontal distance from source**
- **Targets are almost always cables**
 - **For most equipment, cables are the weak spot**
 - **Motor will likely fail because fire damages its power and/or control cables, not because fire overheats the motor itself**
 - **Find out if you are dealing with thermoplastic or thermoset cables**
- **Integrated circuit components also valid targets**
 - **IC components are weaker than their cables**

Task 2.3.4 – Screening Sources


- **This task decides if a given fire ignition source can damage the most vulnerable target and/or spread the fire**
- **We do two types of check:**
 - 1. Zone of Influence (aka Ball and Column)**
 - **Column = Plume heating**
 - **Ball = Radiant heating**
 - 2. Hot gas layer temperature**

Fire Ignition Sources and HRR

- You must consider both the expected and high-confidence HRR values for each source
 - Check the expected HRR (lower) value first
 - If you retain a source at the expected value, then you clearly keep it at the high-confidence value also!
 - If expected value is not enough to retain, then check the high-confidence HRR (higher) value
 - If a fire ignition source screens at both HRR values, then it drops out of the analysis entirely
 - No need to track this fire ignition source any further
 - You may retain a source at its high confidence HRR, and screen it out at its expected value
 - That's OK (more later) and probably will be pretty common

Zone of Influence Chart

- Graphical zone of influence chart
 - Height (H) and radius (R) are from look-up tables
 - Width (W) corresponds to footprint of the source



Zone of Influence - Typical Look-up Table

For fires in an open area away from walls or corners:

Calculated Values (in feet) for Use in the Ball and Column Zone of Influence Chart for Fires in an Open Location Away from Walls				
Fire HRR	Thermoplastic Cables		Thermoset Cables	
	H	R	H	R
70 kW	4.8	1.8	3.5	1.3
200 kW	7.3	3.0	5.3	2.1
650 kW	11.6	5.4	8.5	3.8
2 MW	18.2	9.5	13.3	6.7
10 MW	34.7	21.3	25.3	15.0

Calculations are based on the following damage criteria:

Thermoplastic Cables: 400°F (325°F rise above ambient) and 0.5 BTU/ft²sec

Thermoset Cables: 625°F (550°F rise above ambient) and 1 BTU/ft²sec

Zone of Influence – Fire Location

- Fire location can make a difference – 3 cases:
 - Fires in the open (away from walls)
 - Fires near a wall
 - Fires near a corner
- What do we mean by “near”?
 - Near = within 2 feet of the wall
 - Near a corner = within 2 feet of both walls
- When near a wall or corner, plume effect is “magnified” (2 for a wall, 4 for a corner)
 - Separate H and R look-up tables for these two cases

Zone of Influence

- **If there is at least one target within the zone of influence, then:**
 - **We have the potential for fire spread and/or damage due to plume and radiant heating effects**
 - **The fire ignition source is retained**
- **If there are no targets within the zone of influence, then:**
 - **Fire cannot spread from that particular ignition source to any secondary fuels**
 - **Plume and radiant heating cannot damage any of the potential targets in the room**
 - **Need to check hot gas layer to determine if source must be retained**

Zone of Influence

- **Essentially, the zone of influence chart is a visual check**
 - **Have your HRR and H-R look-up tables handy when you do your walkdown**
 - **You can quickly perform this screening check for most of the sources in the room**
 - **Ballpark distances are OK**
 - **If it looks really close, assume you are right at the threshold and go from there**

Zone of Influence

- If you are dealing with an HRR value not included in the tables (i.e., any one of the standard values) you will have to calculate the H and R values for your fire
- FDT spreadsheets can do this
 - For H – use plume correlation and look for height where plume temperature equals damage threshold
 - Unless it's a pool fire, use a standard fire surface area of 6 square feet
 - For R – use radiant heating correlation and look for distance where flux equals damage threshold
 - Recommend you seek guidance if you are not sure

Task 2.3.4 – Hot Gas Layer

- If a fire source was retained based on the zone of influence, it is retained – period
 - Only need to meet one condition in order to retain
- If a source is already retained, don't bother checking hot gas layer for that source
 - Could save you some time
 - Won't hurt if you check anyway, but it's not necessary at this point
- If you did not retain based on zone of influence, have to check HGL temperature for that source

Hot Gas Layer

- **Check the hot gas layer temperature for any fire ignition sources that had no targets within their zone of influence**
 - **Nothing in the zone of influence means no spread of fire beyond the fire ignition source**
 - **For damage, that means fire source in and of itself has to be enough to create damaging hot gas layer**
- **If such sources can create a hot gas layer temperature above the failure threshold of the weakest target, the source is retained**
 - **This will be rare!**
 - **Need a pretty big source in a pretty small room**

Hot Gas Layer: Process

- The hot gas layer check requires use of the FDT spreadsheet tool
 - Recommendation: Use the natural ventilation spreadsheet and assume an open door (standard commercial door is 36"x 84")
 - Warning: Do not run a zero ventilation case using either natural or forced ventilation spreadsheet – the correlations don't work unless there is some substantial ventilation assumed
- Required inputs:
 - Room dimensions (L-W-H); ventilation conditions; fire HRR
- Record the hot gas layer temperature at 30 minutes
- Compare HGL temperature to target damage threshold
- Fire ignition source screens out if HGL temperature is less than damage threshold

Hot Gas Layer

- Fire location makes no difference for hot gas layer
- That means you don't have to repeat the HGL calculation for each and every fire ignition source
 - Do the HGL calculation once for each unique HRR
 - The answer is the same for all fires sources at that particular HRR

Task 2.3.4 – Summary

- You end up with a screening result for each fire ignition source – three outcomes possible:
 - Source may be retained at both the expected and high-confidence HRR values
 - Source may be retained only at the high-confidence HRR value
 - Source may screen out
- Note that if the source is retained at the expected HRR value, it is also retained (by definition) at its high confidence HRR value

Task 2.3.5 – Screening Check

- If no fire ignition sources were retained, then you failed to identify a credible fire scenario
 - In this case you are done – finding is Green
- This requires that all sources screened out at both their expected and high-confidence HRR values
 - If even one source at one HRR value is retained, you continue to next step

Example Problem – Step 2.3

- Do Step 2.3 for the example problem

Step 2.4 – Refined Fire Frequency

- In this step a refined fire frequency for the fire area is calculated
 - We remove the contribution associated with fire ignition sources that screened out in Step 2.3
 - We apply a severity factor of 0.1 for those sources retained only at their high-confidence HRR value
- Using the refined fire frequency, the quantitative screening check is repeated
 - New information (better fire frequency) may be enough to call a finding Green

Task 2.4.1 – Nominal Fire Frequency

- Enter the results of Task 2.3 into a fire frequency worksheet (or spreadsheet)
 - Count results for retained (unscreened) fire ignition sources
 - Apply severity factors as necessary
 - Sources retained only at high-confidence HRR value get a severity factor of 0.1
 - Sources retained at both the expected and high-confidence values get severity factor of 1.0 (no severity factor reduction)
 - Sources screened out in Step 2.3 are not included in the refined fire frequency
 - Kind of like a severity factor of 0.0

Task 2.4.2 – Findings Quantified Based on Increase in Fire Frequency

- If finding category assigned is anything other than “Fire Prevention and Administrative Controls,” no adjustment made to nominal fire frequency
- Within “Fire Prevention and Administrative Controls” findings, the following fire protection DID elements will result in an increase in the fire frequency
 - Combustible Controls programs
 - For Low or Medium likelihood rating for transient fires, raise the likelihood rating one level
 - For High likelihood rating for transient fires, multiply the likelihood by a factor of 3
 - Hot-work-permitting and/or hot work fire watch provisions
 - Fire area hot work fire likelihood is set to high and the hot work fire frequency for High likelihood is multiplied by a factor of 3

Task 2.4.3 – Credit for Compensatory Measures that Reduce Fire Frequency

- **If compensatory measures are in place and credited with reducing the frequency of transient combustible or hot work fires, assign a compensatory measures adjustment factor of 0.0 to the appropriate fire ignition source scenarios:**
 - **Transient combustible fire frequency**
 - **There are frequent surveillance patrols (at least once per shift) and review of surveillance reports shows no discovery of improperly stored combustibles.**
 - **If finding is against the combustible controls program this provision will not apply – do not reduce fire frequency**
 - **Hot work fire frequency**
 - **Area has not been used for hot work as verified through a review of hot work permits issued.**
 - **If finding is against hot work control requirements (e.g., fire watch) this provision will not apply – do not reduce fire frequency**

Task 2.4.4 – Update Fire Frequency and Do Screening Check

- **The fire frequency for the fire area is revised considering**
 - **Elimination of fire ignition sources that were not retained in Step 2.3**
 - **Application of severity factors for ignition sources retained only at their high-confidence HRR value**
 - **Adjustment factors as applicable for transients and hot work fires**
- **May be done using hand worksheet or electronic spreadsheet**
- **Screening check is essentially identical to that from Step 2.1, but the updated fire frequency is used**

Screening Criteria for Step 2.4

- $\Delta CDF_{2.4} = DF \times (F_{Area2.4}) \times CCDF_{2.1}$

Table A1.6 - Phase 2, Screening Step 4 Quantitative Screening Criteria		
Assigned Finding Category (from Step 1.1):	$\Delta CDF_{2.4}$ screening value	
	Moderate Degradation	High Degradation
Fire Prevention and Administrative Controls	N/A	1E-6
Fixed Fire Protection Systems	1E-5	
Fire Confinement	1E-5 ¹	
Localized Cable or Component Protection	1E-5 ¹	
Post-fire SSD	1E-6	

¹ This entry applies to both 'Moderate A' and 'Moderate B' findings against a fire barrier.

- $\Delta CDF_{2.4}$ is lower than the corresponding value in Table A1.6 - the finding screens to Green and the analysis is complete.
- $\Delta CDF_{2.4}$ is greater than or equal to the corresponding value in Table A1.6. The analysis continues to Step 2.5

Example Problem – Step 2.4

- Do Step 2.4 for the example problem

Step 2.5 – Fire Growth and Damage Scenarios and 2nd Check on SSD

- **In this step the process of defining specific fire scenarios continues**
 - **Fire growth and damage scenarios are defined for each combination of fire ignition source and FDS that we are retaining**
- **This step includes identification of scenario-specific target sets**
- **Once fire growth and damage scenarios are defined, we re-assess survival of the designated SSD path in the context of each fire ignition source**

Step 2.5 – Targets and Target Sets

- **We need to identify targets by both location and function**
 - **We want to know where important targets are with as much accuracy as possible**
 - **Don't start routing cables, but do use routing information made available by licensee**
- **We are going to group individual targets into target sets**
 - **Target sets correspond to fire ignition source/FDS combinations**

Step 2.5 – Target Sets

- We would like to know what function is lost given failure of each target
 - If possible, tie specific targets to specific functions
- As a minimum it is sufficient to know what functions are lost given loss of the entire target set
 - In practice, this is how we use information
 - The greater level of detail is still good information to record as available

Step 2.5 – Target Sets

- **If location information is lacking or uncertain, targets are placed in worst plausible location**
 - **Lacking any other information, assume all target cables are in the tray right above the source**
- **Some rules of thumb may be applied**
 - **Power cables tend to be routed in upper trays**
 - **Control cables are often in lower or mid-level trays**
 - **Instrument cables usually in the lowest trays**
- **When uncertain, err towards conservatism, but use available information**

Task 2.5.1 – Fire Growth And Damage Scenarios

- **Define fire growth and damage scenarios for each combination of an unscreened fire source and FDS**
 - **Define the fire ignition source**
 - **Define a logical path for fire growth for each applicable FDS**
 - **Define the associated target set**

Defining FDS1 Scenarios

Start with a fire ignition source and ask yourself:

- **Q: Was this fire ignition source retained based on targets within the zone of influence?**
 - If yes then we may have an FDS1 scenario to consider
- **Or Q: Was this fire ignition source retained based only on potential for hot gas layer damage (not plume/radiant heating damage)?**
 - If yes, then there will be no FDS1 for that source – might still have FDS2 or FDS3

Defining FDS1 Scenarios

- **FDS1 involves localized damage near the fire source**
- **Focus especially on vertical fire spread/damage (within the fire plume)**
- **Define logical path of fire spread if one exists**
 - **Allow fire to grow vertically (i.e., through a stack of cable trays or up a vertical cable riser)**
 - **Do not postulate substantial horizontal spread – that is for FDS2**
- **Note: we will cover specifics on cable fire spread rules in Module 6**

Defining FDS1 Scenarios

- **FDS1 target set can include any of the following:**
 - **Targets within zone of influence for radiant heating**
 - **The ball in the ball and column**
 - **Targets above the fire source (convective heating zone of influence)**
 - **Targets within the column in the ball and column**
 - **Targets within the range of upward fire spread**
 - **Lowest tray in a stack may be within zone of influence, but target may be a tray ignited due to additional fire spread**
 - **Unprotected cables and components**
 - **Cable and components “protected” by a highly degraded localized fire barrier system**
 - **Non-functional or missing cable wrap**

Defining FDS2 Fire Scenarios

Start with a fire ignition source:

- **Define fire spread path if needed**
 - **If fire source alone is enough to cause damaging hot gas layer, then fire spread is moot – just worry about the source**
 - **If fire ignition source is not enough to cause hot gas layer damage without fire spreading, then you must postulate a path of fire spread**
 - **This time we allow for more extensive horizontal fire spread**
 - **Define in particular, maximum extent of fire possible**

Defining FDS2 Scenarios

- **Define the fire damage target set**
 - **FDS2 involves widespread damage within the fire area**
 - **Look for HGL potential and timing**
 - **If HGL not reasonable or simply takes too long to be risk significant (i.e., high likelihood of suppression), then FDS2 target set may be limited by extent of direct fire spread**
 - **If HGL is possible in reasonable time, any and all exposed cables and components anywhere in the room may be damaged**
 - **Note: anything damaged in the corresponding FDS1 scenario for the same fire source (if you developed one) is also included in the FDS2 target set**

Defining FDS2 Scenarios

- Cables protected by a moderately degraded localized cable or component fire barrier element are also damaged in FDS2
 - These targets will likely drive the overall damage time
- Cables and components protected by a one-hour fire barrier wrap may be damaged in FDS2 even if wrap is not degraded
 - Recall - we did not credit a one-hour wrap alone in Step 2.1 as meeting independence criteria!
 - Any scenario that requires one hour is likely to be relatively low risk, so a “scoping” calculation may be appropriate:
 - Check product of refined fire frequency and manual non-suppression probability at one hour
 - If non-degraded automatic fire suppression system is present, don't chase these scenarios – they will be low risk
- Don't try to fail a non-degraded three-hour fire wrap

Defining FDS3 Scenarios

- The FDS3 scenarios depend a bit on what your finding is – two cases:
 - Finding is not Fire Confinement
 - Finding is Fire Confinement

FDS3 – Finding Is Not Fire Confinement

- The inspected area is always the exposing fire area, an adjacent area is the exposed area
- For this case, something in the fire area you are inspecting is degraded, but it is not the fire area boundaries
- In developing FDS3 scenarios, we are presuming that a fire in the inspected compartment might be more likely to spread to an adjacent compartment
 - Example: It might go unsuppressed for a longer time than one would normally expect

If Step 2.2 Didn't Drop FDS3 You Must Have Found All of the Following:

- **A somewhat weak barrier to at least one adjacent fire area**
- **Questionable or non-existent fixed suppression capability in exposing compartment**
- **Unique and exposed targets in at least one adjoining room**
- **The potential for fire that can directly challenge the fire barrier**

It's not hard to develop an FDS3 scenario out of that situation!

FDS3 – Finding Is Fire Confinement

- In this case you have a degraded fire barrier between two fire areas
- Fire spreading through the degraded barrier **IS** the scenario
- Fire might go in either direction, so you may have two scenarios
 - Hopefully the screening question would eliminate fire in one direction or the other
 - If one fire area has a non-degraded fire sprinkler system, that should not be the exposing fire area

For Both Cases: Defining The FDS3 Scenarios

- Focus only on fire getting through the barrier(s) that did not meet the screening rules
 - The degraded barrier or the one that didn't give at least 2 hours endurance
 - If endurance rating is greater than 20 minutes, but less than 2 hours, your targets in the exposed room should be right near the barrier
 - If it's less than 20 minutes or barrier is degraded, targets could be anywhere in the exposed room
- Focus on fire ignition sources that could challenge the fire barrier
 - High hazard
 - Near barrier
 - Direct path for fire spread through the barrier

Defining FDS3 Scenarios

- **Again, start with a fire ignition source**
 - **Pick the worst one and let it represent the whole set**
 - **You want one that can spread fire or fire effects into the adjacent area**
 - **If you applied the screening rules in Step 2.2 correctly, then you should have verified at least one such source existed**
- **Characterize the conditions that lead to fire spread into the adjacent fire area**
 - **Fire spread along cable trays that penetrate the barrier is typical**
 - **If you have a high-hazard fire source (e.g., oil-filled transformer or other large oil source), source of spread could be hot gas layer impacting both fire areas**

Defining FDS3 Scenarios

- **Target set should be pretty obvious**
- **Minimum set:**
 - **Everything within reach of your ignition source (zone of influence)**
 - **Everything in the path of fire spread**
 - **The unique targets in the exposed fire area**
- **Maximum:**
 - **Everything in both fire areas**
- **Use your judgment, pick a target set**

Task 2.5.2 – Plant Damage State

- **For each fire growth and damage scenario determine what failure of the target set means in the context of plant SSD response**
 - **What functions/systems are lost**
 - **What is the nature of the failure**
 - **Loss of function, spurious operation, operable but with loss of indication....**
 - **What is function/system state given failure**
 - **System may be running**
 - **Valve may be open or closed...**
- **Recall – it is enough to know this answer for the set as a whole, but nice if you can tie functions to specific targets**

Plant Damage State

- Also define what survives
 - What functions/systems can be credited for safe shutdown
 - Assume system is lost unless it can be verified with reasonable confidence that the system will survive
- Identify any manual actions needed to support safe shutdown
 - Focus on actions outside the main control room or complex actions within the main control room

Task 2.5.3 – Re-Check SSD Path Independence

- **In this task the independence of the designated SSD path is re-assessed based on the specific plant damage state**
 - **Plant damage state will define whether or not the SSD path is available – no more rules/questions needed**
- **You look at the worst case target set for each fire ignition source**
 - **If the SSD path survives in this worst case, the CCDP from Step 2.1 (e.g., 0.1) can be applied to all scenarios for that fire ignition source**

Step 2.5.4 – Screening Check

- In this step, the SSD path is credited, or not credited, for each fire ignition source
 - CCDP for each ignition source is either 1.0 or $CCDP_{2.1}$ depending on results of Step 2.5.3
- If the SSD path is lost for at least one fire scenario for each fire ignition source, then this step is skipped
 - You can only improve screening result if you are going to credit the SSD path for at least one fire ignition source
- If you decided earlier that $CCDP_{2.1}$ applied in general, then there is no benefit to be gained

Step 2.5.5 – Screening Check

$$\Delta CDF_{2.5} = DF \times \sum \{(F_{\text{source}})_i \times (CCDP_{2.1})_i\}$$

- Sum over all fire ignition sources (i=1 to n)

Table A1.8 - Phase 2, Screening Step 5 Quantitative Screening Criteria		
Assigned Finding Category (from Step 1.1):	$\Delta CDF_{2.5}$ screening value	
	Moderate Degradation	High Degradation
Fire Prevention and Administrative Controls	N/A	1E-6
Fixed Fire Protection Systems	1E-5	
Fire Confinement	1E-5 ¹	
Localized Cable or Component Protection	1E-5 ¹	
Post-fire SSD	1E-6	

¹ This entry applies to both 'Moderate A' and 'Moderate B' findings against a fire barrier.

- The value of $\Delta CDF_{2.5}$ is lower than the corresponding value in Table A1.8. The finding Screens to Green, and the analysis is complete.
- The value of $\Delta CDF_{2.5}$ exceeds the corresponding value in Table A1.8. The analysis continues to Step 2.6.

Example Problem – Step 2.5

- Do Step 2.5 for the example problem

Step 2.6: Damage Time

- Estimate fire growth and damage time for each fire scenario
- There are separate “rules” for FDS1, FDS2, and FDS3
 - Task 2.6.1 – FDS1
 - Task 2.6.2 – FDS2
 - Task 2.6.3 – FDS3
- FDS1 and FDS2 require use of FDTs (plume, radiant heating, hot gas layer)
- Fire spread rules also apply

Task 2.6.1: FDS1

- If all elements of the target set are within the zone of influence then plume/radiant heating is enough – don't need fire spread
 - Calculate plume temperature or radiant heat flux level at target location
 - Pick damage time off the look-up table
- If target tray is outside the zone of influence, fire spread upwards through the cable tray stack is needed
 - Use the cable tray fire growth rules
 - Details in Attachment 3

Fire Spread In A Tray Stack:

- If first tray is within zone of influence it can be ignited and fire will spread
- Fire spreads according to the following rules:
 - Time to ignition of first tray: use plume temperature at height of tray and time to damage/ignition table
 - Call this t_1
 - Note: Early versions of guidance said to use five minutes but this was an error and has been corrected in current version
 - Second tray 4 minutes later (elapsed time $t_1 + 4$ min.)
 - Third tray 3 minutes later (elapsed time $t_1 + 7$ min.)
 - Fourth tray 2 minutes later (elapsed time $t_1 + 9$ min.)
 - Fifth tray 1 minute later (elapsed time $t_1 + 10$ min.)
 - Higher trays 1 minute later (elapsed time $t_1 + 11$ min.)
- Cables assumed to fail when tray ignites

Task 2.6.2 – FDS2 Damage Time

- **Begin with corresponding FDS1 damage time if there is one for the fire ignition source**
 - **FDS2 damage time cannot be any earlier**
- **Then you need to go after the hot gas layer, and consider time to damage for degraded raceway fire barriers**

FDS2 Damage Time

- **Targets with no fire barrier protection are damaged based on exposure temperature and time-to-damage table**
- **If FDS2 target sets include cables or components within a moderately degraded local fire barrier system, add in the remaining performance time of the barrier, given the degradation, to get total time to damage**

HGL Damage

Check the HGL temperature for the fire ignition source alone (using FDTs) – if this is enough:

- If HGL temperature reaches damage threshold in less than 30 minutes, then ignition source alone is enough to cause damage**
 - You may have checked this during screening back in Step 2.4**
- First check HGL temperature at 10 minutes**
 - If this value exceeds the damage threshold, record the value, use the look-up table to get damage time at this temperature**
 - Total damage time is 10 minutes plus time to damage from look-up table**
- If HGL temperature reaches damage threshold in greater than 10 minutes:**
 - Damage time is time to reach damage threshold plus damage time from look-up table at the threshold temperature (e.g., 28 minutes)**

HGL Damage

If fire spread to cables is needed to get damaging HGL, process requires use of both FDTs and Cable Tray Fire Spread spreadsheets:

- **FDT HGL tool: Determine HRR needed to get damaging HGL in the room of interest**
 - **Input room parameters (dimensions, ventilation)**
 - **Adjust HRR for the fire**
 - **Look at HGL temperature at 10 minutes**
 - **Compare to damage threshold temperature**
 - **Iterate until HGL temperature equals or exceeds damage**

HGL Damage

- Fire ignition source contributes to total HRR, so subtract that out from required HRR
 - The HRR difference needs to come from the cables
- Have to figure out time for fire to spread far enough to create a fire this big:
 - Cable trays are assumed to burn at 400 kW/m²
 - Calculate square feet of tray required to get required HRR
 - Determine if there are enough trays in the area to get a fire this big
 - If no, then FDS2 scenario is not credible
 - If yes, need to estimate time for fire to grow this far using cable tray fire spread rules
 - Spreadsheet provided for this case

HGL Damage

- If there are enough trays, use the Cable Tray Fire Spread spreadsheet (“Time to HGL From Fire Spread_Locked.xls”):
 - Calculate time to ignition of first tray
 - Using plume temperature at tray and damage time look-up table (as in a FDS1 scenario)
 - Spreadsheet input: total HRR needed, ignition source HRR, time to ignition of first tray, characteristics of cable trays
 - Manipulate “time of interest” until damaging HGL is indicated
- That puts us at the damage threshold
 - Assume pre-heating of exposed cables during time of fire growth so no additional time to damage
 - Time to develop damaging HGL is taken as time to damage exposed cables for fire propagation scenarios
 - Cables with fire barrier wrapping get additional time
 - Nominal fire barrier rating (after applying penalty for any degradation)
 - Plus $\frac{1}{2}$ of time to damage for cable at threshold condition

HGL Damage

- **Don't try to get too fine an answer:**
 - **HRR steps of 50 kW**
 - **Time steps of integer minutes**

Task 2.6.3: FDS3 Scenarios

- **If you have a highly degraded fire barrier as the finding, combine the two areas and treat just like FDS2**
 - **Inter-area barrier gets no credit**
 - **Credit only one fire suppression system if more than one exists (i.e., you might have had some coverage in both rooms)**

Task 2.6.3 – FDS3 Scenarios

- If you have a moderately degraded barrier or a finding that is not Fire Confinement
 - Use one scenario to estimate time for direct fire spread to and through the fire barrier
 - Estimate time for fire to spread to the barrier
 - Use one scenario (same or other) to try to get a damaging hot gas layer
 - Use FDS2 approach to estimate time to reach a damaging hot gas layer in the exposing fire area
 - Pick the shorter time from these two cases to represent all FDS3 fires
 - This is the fire growth time

Task 2.6.3 – FDS3 Scenarios

- **Moderate degradation Fire Confinement or non-confinement finding (cont.)**
 - **Add in the fire endurance time allowed for the degraded barrier [e.g., 65% (Moderate A) or 35% (Moderate B) of nominal if barrier is degraded or full credit if not]**
 - **If targets in exposed fire area have raceway fire barrier protection, add in the fire endurance rating of this protection**

Total fire damage time = (fire growth time) + (endurance of degraded barrier) + (endurance of raceway barriers is present in exposed compartment)

Example Problem – Step 2.6

- Do Step 2.6 for the example problem

Step 2.7 – PNS Analysis

- **This step estimates the probability that suppression fails at extinguishing fire before target set is damaged**
- **Credit is given to both fixed and manual fire suppression**
- **For the fire brigade, we also need the detection time**
 - **Detection activates the human response including the fire fighting response**

Task 2.7.1 – Fire Detection Time

Detection time is a race – shortest time wins:

- Fixed fire detection is estimated using FDT spreadsheet
- Other means of detection
 - Continuous fire watch: $t_{\text{detection}} = 0$
 - Roving fire watch: $t_{\text{detection}} = \frac{1}{2}$ the duration of roving patrol
 - General plant personnel:
 - $t_{\text{detection}} = 5$ minutes if continuously manned
 - $t_{\text{detection}} = 15$ if not manned
 - Maximum detection time is 15 minutes

Task 2.7.2 – Fixed Fire Suppression

- **Activation of fixed fire suppression system that is considered effective against the fire ignition source is assumed to end the fire scenario**
 - **Inspector decides on suppression system effectiveness**
 - **Timing needs to be determined**
- **Skip this task if no fixed suppression exists or installed system is highly degraded**

Task 2.7.2 – Fixed Fire Suppression

- **Use the fire detector spreadsheet in FDTs to estimate actuation time**
 - **Sprinkler head is just a fancy heat detector**
- **Watch for cross-zoned actuation logic**
 - **Common for auto gas systems and deluge systems**
 - **Need to ensure both zones actuate, so analyze detector that is farthest from the fire source**
- **Add discharge delay time for gaseous systems**
 - **Minimum of 30 seconds, 1-2 minutes is typical**

Task 2.7.2 – Fixed Fire Suppression

- **If fixed suppression system is moderately degraded:**
 - **If issue is head spacing – model as found**
 - **If some subset of discharge heads are degraded then assume nearest head won't work, second closest head is modeled**
 - **If system does not provide adequate coverage to some fire ignition sources, credit only for those sources that are covered**

Task 2.7.2 – Fixed Fire Suppression

- **If fixed system is manually actuated**
 - **Estimate the fire brigade response time**
 - **If fire brigade members have full decision-making authority to actuate system, allow additional 2 minutes for situation assessment and decision-making**
 - **If fire brigade must get authorization (e.g., from MCR, shift supervisor, plant manager) you must assess the time required for such authorization**
 - **Don't forget delay time for gaseous system discharge applies even when manually actuated**

Task 2.7.2 – PNS_{fixed}

- Now that you have time to actuation and time to damage, the two are compared in order to assess the value of PNS_{fixed}
 - Take the difference:
 - $t_{\text{damage}} - t_{\text{supp_fixed}}$
 - Refer to lookup table for PNS
- Both times have uncertainty
 - If difference is small, we don't allow as much credit as when difference is large

The PNS_{fixed} lookup table

Probability of Non-suppression for Fixed Fire Suppression Systems Based on the Absolute Difference Between Damage Time and Suppression Time	
Time Delta: ($t_{Damage} - t_{Suppress}$)	PNS_{Fixed}
Negative Time up to 1 Minute	1.0
> 1 Minute to 2 Minutes	.95
> 2 Minutes to 4 Minutes	.80
> 4 Minutes to 6 Minutes	.5
> 6 Minutes to 8 Minutes	.25
> 8 Minutes to 10 Minutes	.1
> 10 Minutes	0.0

Task 2.7.3 – Manual Suppression

- **Manual suppression is based on empirically fire duration curves**
 - **Analysis of historical events**
 - **Based on total fire duration so we don't do brigade response time – built into curves**
- **Different curves for different fire ignition sources**
 - **Pick the curve that applies to your ignition source**
 - **Example: If fire spreads from a panel to cable trays, the ignition source was the panel, use the electrical fire curve rather than the cable fire curve**

Task 2.7.3 – Manual Suppression

- “Curves” are available in three forms
 - Graphical
 - Look-up table
 - Equation:

$$PNS_{manual} = \exp[-\lambda \times t]$$

- Values of suppression rate constant (λ) are in look-up table
- t is fire duration (time to damage minus time of detection)

Degraded Gaseous System PNS Analysis

First calculate PNS for manual response as if gaseous system were not in place (or were to fail):

- **Select appropriate fire duration curve, based on ignition source**
- **Estimate fire detection time in the usual manner**
 - **Assume a valid actuation signal for gaseous system will trigger fire detection signal as well**
- **Calculate $t_{\text{damage}} - t_{\text{detection}}$**
- **Estimate $\text{PNS}_{\text{manual}}$ in the usual manner**

Degraded Gaseous System PNS Analysis

Next look at timeliness of system discharge:

- Estimate discharge/actuation time (t_{suppress}) as you would for any fixed system
 - Could be automatic or manual actuation of fixed system
- Calculate time margin (“Time Delta”) between actuation time and fire damage time in the normal manner:
 - Time Delta = (t_{damage} - t_{suppress})
- Use the general PNS_{fixed} probability table (IMC, 0609, App F, Att 8, Table A8.2) to assess probability that suppression system actuation is timely in relation to estimated fire damage time.

Degraded Gaseous System PNS Analysis

Based on PNS_{fixed} decide whether to credit gaseous system:

- If PNS_{fixed} is 1.0, then gaseous system will not be credited.
 - Use $PNS_{\text{scenario}} = PNS_{\text{manual}}$
 - Analysis is complete.
- If PNS_{fixed} is less than 1.0, then gaseous system will be credited.
 - Continue this analysis to estimate PNS_{scenario}

Degraded Gaseous System PNS Analysis

Now do the case where system buys some added time for fire brigade response:

- Calculate modified fire damage time as follows:

$$t_{\text{damage_new}} = t_{\text{damage}} + t_{\text{maintain_gas}}$$

where $t_{\text{maintain_gas}}$ is the time suppressant concentration can be maintained

- Calculate modified time available for manual suppression:

$$[t_{\text{damage_new}} - t_{\text{detection}}]$$

- Estimate $\text{PNS}_{\text{gas_manual}}$ in the manner normally applied to $\text{PNS}_{\text{manual}}$
 - Use appropriate fire duration curve with the modified time available

Degraded Gaseous System PNS Analysis

To get final PNS_{scenario} combine three cases:

- **Case 1:** Suppression system works (0.95 - no random failure), the actuation is timely ($1 - PNS_{\text{fixed}}$), and fire brigade fails to respond with extra time available ($PNS_{\text{gas_manual}}$)
- **Case 2:** Suppression system works (0.95 - no random failure), but discharge of the fire suppression system is not timely (PNS_{fixed}), manual brigade must respond within original fire damage time (no extra time available – PNS_{manual})
- **Case 3:** Gaseous suppression system suffers random failure on demand (0.05), fire brigade must respond within the originally estimated fire damage time (PNS_{manual})

Degraded Gaseous System PNS Analysis

- And the final reduced equation is...

$$\text{PNS}_{\text{scenario}} = 0.95 \times (1 - \text{PNS}_{\text{fixed}}) \times \text{PNS}_{\text{gas_manual}} + [(0.95 \times \text{PNS}_{\text{fixed}}) + 0.05] \times \text{PNS}_{\text{manual}}$$

- Verify that ($\text{PNS}_{\text{scenario}} \leq \text{PNS}_{\text{manual}}$)
 - As in other cases, the manual brigade response given the original fire damage time is the minimum credit given to fire suppression for any scenario
 - If ($\text{PNS}_{\text{scenario}} > \text{PNS}_{\text{manual}}$) reset ($\text{PNS}_{\text{scenario}} = \text{PNS}_{\text{manual}}$)

Task 2.7.4: Final combined PNS

For water-based systems:

$$\text{PNS}_{\text{scenario}} = (0.98 \times \text{PNS}_{\text{fixed-scenario}}) \\ + (0.02 \times \text{PNS}_{\text{manual-scenario}})$$

For Gaseous systems:

$$\text{PNS}_{\text{scenario}} = (0.95 \times \text{PNS}_{\text{fixed-scenario}}) \\ + (0.05 \times \text{PNS}_{\text{manual-scenario}})$$

$$** \text{PNS}_{\text{scenario}} \leq \text{PNS}_{\text{manual-scenario}}$$

And The Degraded Gaseous System – Inadequate Soak Time Case

$$\begin{aligned} \text{PNS}_{\text{scenario}} &= 0.95 \times (1 - \text{PNS}_{\text{fixed}}) \times \text{PNS}_{\text{gas_manual}} \\ &+ [(0.95 \times \text{PNS}_{\text{fixed}}) + 0.05] \times \text{PNS}_{\text{manual}} \end{aligned}$$

Step 2.7.5 – Screening Check

- **We now have scenario-specific PNS**
- **Combine with duration factor, scenario-specific frequency, and scenario-specific credit for SSD path to get new screening result**
- **Screen to Green if increase in CDF is less than $1\text{E-}6$**

Example Problem – Step 2.7

- Do Step 2.7 for the example problem

Step 2.8 – SSD / CCDP Analysis

- **Won't go into detail**
 - **Task 2.8.1 – Select appropriate plant initiating event worksheet (guidance on p. F-40)**
 - **Task 2.8.2 – Identify credited systems and functions**
 - **Task 2.8.3 – Identify ex-control room actions**
 - **Task 2.8.4 – Assess failure probability of manual actions**
 - **Task 2.8.5 – Assess CCDP**

Step 2.9 – Final Quantification

- In this step you use all your best information, which now includes a specific CCDF for each individual scenario
- Run these values through the risk equation
- Sum scenario frequencies
- Assign a preliminary color

Table 2.9.1- Risk Significance Based on Δ CDF	
Frequency Range/ry	SDP Based on Δ CDF
$\geq 10^{-4}$	Red
$< 10^{-4} - 10^{-5}$	Yellow
$< 10^{-5} - 10^{-6}$	White
$< 10^{-6}$	Green



Idaho National Laboratory

Intentionally Left Blank

Module 6: Special Topics



Idaho National Laboratory

Module 6A – High Energy Arcing Faults In Electrical Distribution And Switching Equipment

High Energy Arcing Faults

- **Arcing faults are not your typical fire**
 - **High energy discharge at the outset – essentially a small explosive discharge**
 - **Usually started due to either phase-to-phase or phase-to-ground shorts and arcing**
 - **Often following a maintenance activity**
 - **Electrical energy is converted to heat – lots of heat – for a very short time**
 - **Copper electrical contacts get vaporized**
 - **Arcs can burn through steel in very short order**

Our Prototypical Event

- **San Onofre, Unit 3, Feb. 3, 2001**
 - Discussion based largely on presentation by Bob Richter at 10/01 NEI FP Forum
 - Additional information in App. H of NUREG-1824
- **Picture at right shows panel after the fire**
 - Some damage was done during fire fighting (large mass bottom center pulled free of panel)
 - Note extensive burn marks




What Happened


- While “racking in” one of the two main input breakers for one train of switchgear, the “stabs” for one phase did not make proper/full contact
- Arcing vaporized the copper contacts
- Arcing burned a hole through the side of the panel
- The ionized smoke and copper plasma propagated to the second main input breaker in an adjoining panel
- Arcing in the second breaker cubicle caused a catastrophic arcing fault and explosion

What Happened


- The door to the second panel was blown open
- The ensuing fire caused loss of overhead cable trays, adjoining switchgear breaker cubicles, and panels located across the aisle from the initially faulting switchgear
- Total fire duration was over one hour
- Numerous attempts to extinguish fire with dry chemical were unsuccessful; water required to put out deep-seated fire



Sketch 1: C Contact arcing and Phase to Phase to ground arcing in Cabinet 3A0712.



Sketch 2: Ionized gas transits from 12 to 14 and into 13. Conductive bridge across 14 Reserve stabs causes flash.




Sketch 3: Main Generator continues to feed A-B-C-Ground arcing in 12. A-phase arcs to ground in 14 causing Differential trip.

Assessment Of Causes

- **Most Likely Causes For A07 Fire**
 - **1. Mispositioning of stud-to-pushrod interface among the 3 phases.**
 - **2. Improper bridge pivot joint pressure**
 - **3. Arc chute degradation leading to foreign material between breaker contacts**

U3 A07 30' Switchgear Room Bus & Cable Tray Arrangement



U3 A07 30' Switchgear Room Cable Trays

**Cable
Tray
Directly
Above
Bus
A07**



U3 A07 30' Switchgear Room Cable Trays



Cable Tray Directly Above Bus A07

U3 A07 30' Switchgear Room Cable Trays



Second Level Cable Tray above Bus A07

U3 A07 30' Switchgear Room Cable Trays

**Second Level Cable
Tray
Above Bus A07**



U3 A07 30' Switchgear Room Cable Trays



Third Level Cable Tray Above Bus A07

U3 A07 30' Switchgear Room Cable Trays

**Third Level Cable
Tray above Bus
A07**



Effects Of Initial Pressure Spike

- **Back door of Cubicle 14 blown off by high pressure pulse**
- **Soot pattern shows that pulse originated in lower right corner at Phase A input**





- **Upper section of panel**



- **Holes in sides of 3A0712 cubicle caused by arcing. Left: A phase to ground, right: C phase to ground**

Fire Characterization Rules For SDP

- **Consider arcing faults for certain types of equipment**
 - **440V and up only**
 - **Switchgear, breakers, motor control centers only**
 - **Frequency given in worksheet for applicable fire ignition sources**
 - **Separate values given for thermal fires and HEAF**
 - **Both apply! (two for one sort of thing)**
 - **HEAF frequency is per panel section just like any other fire frequency**

Initial Energetic Release

- Assume that the door(s) to the faulting cubicle are blown open (creates an open panel fire)
- Assume that equipment in the first neighboring cubicle/panel in each direction will also be damaged
 - An empty panel section will not stop propagation of initial fault (as shown by San Onofre event)
 - Go to first occupied section
- Initial fault assumed to actuate next higher level of circuit protection
 - A fault in one switchgear cubicle will cause a loss of power to the entire bank because the input power will trip offline
 - Not recoverable (until the initial fault is isolated)

Enduring Fire

- The enduring fire created by HEAF is treated using only one fire size: 200 kW
 - Severity factor is 1.0
 - Don't use expected and high-confidence approach, all fires caused by HEAF are 200 kW
- If there are any trays above the faulting panel, the first/lowest tray in each stack will be ignited at time 0 so long as it is within 5 feet of the top of the panel
 - Propagate fire through additional trays using general rules for cable tray fire growth
- Any combustible materials within 3 feet horizontally of the front or rear surface of the panel will ignite at time zero
 - Damage targets in the same region fail at time zero

Module 6B – Cable Tray Fires

Fires In Cable Tray Stacks

- Fire spread is rule-based
- Two specific pieces of info used:
 - Fires will release 400 kW per square meter of cable tray
 - Fires will propagate horizontally at 10 feet per hour
- No distinction made between thermoset and thermoplastic cables

Exposure Fires And Ignition Of Lowest Tray

- First decide if you can ignite the lowest tray
 - Is lowest tray within zone of influence?
 - Yes \Rightarrow fire can spread to other trays
- Use FDT to calculate plume temperature at location of lowest tray
 - Use distance to tray bottom
- Assume lowest tray ignites based on plume temperature and time to damage/ignition table
 - Call time to ignition of lowest tray t_1

Spread To Subsequent Trays

- Additional trays are ignited as follows:
 - Second tray 4 minutes later (elapsed time $t_1 + 4$ min.)
 - Third tray 3 minutes later (elapsed time $t_1 + 7$ min.)
 - Fourth tray 2 minutes later (elapsed time $t_1 + 9$ min.)
 - Fifth tray 1 minute later (elapsed time $t_1 + 10$ min.)
 - Higher trays 1 minute later (elapsed time $t_1 + 11$ min.)
- Cables assumed to fail when tray they are in ignites
- Separation distance does not matter!
 - Be reasonable – a good size fire can easily jump a few feet of vertical separation – 8'-10' is limit for most fires
 - If in doubt, you can use FDT to see if fire will jump vertical gap
 - Assume the entire fire (total fire intensity) is in the highest tray you are confident will ignite
 - Compare plume temperature at next tray to failure/ignition threshold

More Than One Stack?

- **Ignite lowest tray in adjacent stack at time that third tray in initial stack ignites**
- **Fire spread in second stack then follows the tray-by-tray spread of initial stack, always lagging by two trays until entire stack is involved**

Self-Ignited Cable Fires

- Fire starts within a cable tray due to a fault in the cables
- Only considered for cables that do not meet IEEE-383 low flame spread standard
 - This is the only place we talk about qualified vs. unqualified instead of thermoplastic vs. thermoset
 - Most industry cables are qualified – ask licensee!
 - Watch PE/PVC cables – may be qualified or may be unqualified
- Meeting the flame spread standard is enough in this case – don't need all the additional EQ environmental exposure stuff

Self-Ignited Cable Fires

- **Find: of all the places the fire might ignite, what are the critical locations**
 - **The place or set of places where the fire will do the worst damage**
- **We apply a weighting factor to fire frequency to reflect percentage of trays represented by the critical location**
 - **$WF = (\text{Linear feet of tray in critical location}) / (\text{Total linear feet of tray in the room})$**
 - **ESTIMATE – don't pull out the tape measure**

Self-Ignited Cable Fires

- From there the same fire spread rules apply as for other fire scenarios



Module 6C – Reverse Engineering The Hot Gas Layer

Hot Gas Layer

- FDS2 involves hot gas layer damage
- In few cases will any single fire ignition source burning by itself be enough to create a hot gas layer
 - Check your case, but you need a big fire in a small room
 - Exceptions might be large oil fires, oil filled transformers
- That usually means the fire has to spread to create a damaging hot gas layer
- Fire spread takes time, and the question boils down to how much time?

Hot Gas Layer

- **We work this problem backwards**
 - **Use the FDT hot gas layer tool to estimate the fire size (i.e., HRR) required to cause a damaging hot gas layer**
 - **Figure out how much fire spread is needed to create a fire that big**
 - **Figure out how much time is needed to spread fire that far – that is damage time**

Hot Gas Layer

- **First, using FDT, decide how big a fire it takes to get damaging HGL**
 - **Start with HRR of the fire ignition source**
 - **If HGL temperature at 10 minutes is greater than or equal to the damage threshold**
 - **Use HGL temperature at 10 minutes**
 - **Use damage time table for the calculated temperature**
 - **Total time to damage is 10 minutes plus damage time from look-up table**
 - **Implies minimum time of 10 minutes**
 - **If HGL temperature reaches threshold within 30 minutes**
 - **Time to damage is time to reach damaging HGL plus damage time at damage threshold (e.g., 28 minutes)**

Hot Gas Layer

- If fire ignition source is not enough (HGL temperature doesn't reach damage threshold within 30 minutes) fire spread is needed to create damaging hot gas layer
 - If fire spread is not possible (no ignition targets within zone of influence), then this is not a credible FDS2 scenario – drop scenario
- If fire spread is possible (at least one ignition target within zone of influence), increase fire size in FDT until temperature at 10 minutes reaches damage threshold and record required HRR
 - Don't try to get too fine an answer, steps of 50 kW are fine

Hot Gas Layer

- Now we have to figure out how far the fire has to spread to create a fire this big:
 - You will look for a fire spreading into cable trays
 - Cable trays are assumed to burn at 400 kW/m²
 - Calculate square meters (or square feet) of tray required to get fire size needed
 - Remember – the ignition source is also burning, trays only have to make up the difference: subtract out HRR for ignition source
 - Determine if there are enough trays in the area to get a fire this big
 - If no, then the FDS2 scenario is not credible
 - If yes, need to estimate time for fire to grow this far using cable tray fire spread rules

Hot Gas Layer

- Once we have extent of fire needed, we have to reverse engineer the cable tray fire spread model
 - Time to ignite first tray (t_1) comes from plume temperature and time to damage/ignition – FDS1
 - Remaining trays propagate as normal:
 - Second tray – $t_1 + 4$ min.
 - Three trays – $t_1 + 7$ min.
 - Four trays – $t_1 + 9$ min
 - Five trays – $t_1 + 10$ min.
 - Rest of stack – $t_1 + 11$ min.
 - Spreadsheet will do this for you!

Hot Gas Layer

- **Given following information it's cookbook:**
 - **Total HRR needed to get damaging HGL**
 - **HRR for fire ignition source (subtracted from above total HRR)**
 - **How many trays in the stack**
 - **Time to first tray ignition**
 - **Width of trays or cable bundles**
- **Spreadsheet does the cooking for you**

Module 6D: Flexibility

Let's Talk About Flexibility

- It is common for PRA practitioners to exercise flexibility in the order in which they pursue the quantification steps/factors
- It is the intent that SDP retain this flexibility
 - You will have to use your judgment
- Discussed in IMC 0308, Att. 3, App. F

Flexibility

- This is going to take practice and confidence on your part
- Flexibility is not necessary, you will get to the same answer either way, but you may save time/effort
- Exercising flexibility is most effective for a finding that is going to go Green in the end anyway
 - Question is, “is there a quicker path to a screening result?”
- Biggest challenge is to ensure you don’t double count

One Caution On Flexibility

- **If you alter the order of steps, you need to use the screening criteria that go with the step that moved up in the process**
 - **For example, if you move Step 2.8 (refined CCDP) up to the top of Phase 2, you need to use the 1E-6 general screening criterion, not the tables in Step 2.1**

Flexibility Example 1:

- Impacted fire area has very few fire ignition sources or sources present are not significant
 - It may be desirable to develop refined fire frequency early
 - Helps most if close to screening level already, or when all sources are likely to screen out
 - May get you the “no credible fire scenario” answer
 - Move fire ignition source counting/screening to first task in Phase 2
 - Can use refined fire frequency in subsequent steps

Flexibility Example 2:

- **Existence of diverse SSD paths not threatened by possible fire scenarios**
 - **May be desirable to pursue CCDP early in Phase 2 – e.g., put Step 2.8 before Step 2.1**
 - **Use refined CCDP in subsequent steps in place of nominal CCDP value from Step 2.1**
 - **You may avoid need to develop specific fire scenarios altogether**

Flexibility Example 3:

- Redundant tray is in room, but in non-degraded one-hour fire wrap
- Q: Is it worth pursuing scenarios that attack the redundant tray in detail?
 - Scoping calculation can estimate importance
 - Look at manual non-suppression probability at one hour (we will give the minimum 1-hour credit to non-degraded barrier regardless)
 - Multiply by room fire frequency (either Phase 1 or Phase 2 refined value)
 - Loss of redundant train usually means can't credit SSD, so CCDP=1
 - Product of $DF \times PNS_{\text{manual}} \times F_{\text{room}}$ bounds contribution of these scenarios
 - If product is low enough, (i.e., well below $1E-6$) you may not want to analyze these scenarios in further detail.