

SURVEILLANCE REQUIREMENTS

SURVEILLANCE		FREQUENCY								
SR 3.4.3.1	<p>Verify the safety function lift setpoints of the required S/RVs are as follows:</p> <p>-----NOTE-----</p> <p>Up to two inoperable required S/RVs may be replaced with spare OPERABLE S/RVs having lower setpoints until the next refueling outage.</p> <p>-----</p> <table><tr><th><u>Number of S/RVs</u></th><th><u>Setpoint (psig)</u></th></tr><tr><td>2</td><td>1175 (≥ 1140 and ≤ 1210)</td></tr><tr><td>6</td><td>1195 (≥ 1160 and ≤ 1230)</td></tr><tr><td>8</td><td>1205 (≥ 1169 and ≤ 1241)</td></tr></table> <p>Following testing, lift settings shall be within $\pm 1\%$.</p>	<u>Number of S/RVs</u>	<u>Setpoint (psig)</u>	2	1175 (≥ 1140 and ≤ 1210)	6	1195 (≥ 1160 and ≤ 1230)	8	1205 (≥ 1169 and ≤ 1241)	In accordance with the Inservice Testing Program
<u>Number of S/RVs</u>	<u>Setpoint (psig)</u>									
2	1175 (≥ 1140 and ≤ 1210)									
6	1195 (≥ 1160 and ≤ 1230)									
8	1205 (≥ 1169 and ≤ 1241)									

SURVEILLANCE REQUIREMENTS

SURVEILLANCE		FREQUENCY								
SR 3.4.3.1	<p>Verify the safety function lift setpoints of the required S/RVs are as follows:</p> <p>-----NOTE-----</p> <p>Up to two inoperable required S/RVs may be replaced with spare OPERABLE S/RVs having lower setpoints until the next refueling outage.</p> <p>-----</p> <table><tr><th><u>Number of S/RVs</u></th><th><u>Setpoint (psig)</u></th></tr><tr><td>2</td><td>1175 (≥ 1140 and ≤ 1210)</td></tr><tr><td>6</td><td>1195 (≥ 1160 and ≤ 1230)</td></tr><tr><td>8</td><td>1205 (≥ 1169 and ≤ 1241)</td></tr></table> <p>Following testing, lift settings shall be within ±1%.</p>	<u>Number of S/RVs</u>	<u>Setpoint (psig)</u>	2	1175 (≥ 1140 and ≤ 1210)	6	1195 (≥ 1160 and ≤ 1230)	8	1205 (≥ 1169 and ≤ 1241)	In accordance with the Inservice Testing Program
<u>Number of S/RVs</u>	<u>Setpoint (psig)</u>									
2	1175 (≥ 1140 and ≤ 1210)									
6	1195 (≥ 1160 and ≤ 1230)									
8	1205 (≥ 1169 and ≤ 1241)									